

Repair-Parts



Reactor 2 E-30 and E-XP2


Proportioning System

333024G
EN

Electric, Heated, Plural Component Proportioning System. For spraying polyurethane foam and polyurea coatings. For professional use only. Not approved for use in explosive atmospheres or hazardous locations.



Important Safety Instructions. Read all warnings and instructions in this manual. Save these instructions.








ti20577b












Contents









| | | | |
|--|----|--|-----|
| Warnings | 3 | Replace Pressure Transducers | 59 |
| Important Isocyanate Information | 7 | Replace Fans | 60 |
| Models | 9 | Repair Primary Heater | 62 |
| Approvals | 11 | Repair Heated Hose | 66 |
| Accessories | 11 | Repair Fluid Temperature Sensor (FTS) | 68 |
| Supplied Manuals | 12 | Replace Power Supply | 71 |
| Related Manuals | 12 | Replace Surge Protector | 71 |
| Troubleshooting | 13 | Replace Advanced Display Module (ADM) | 71 |
| Troubleshoot Errors | 13 | Replace Motor Control Module (MCM) | 72 |
| Pressure Relief Procedure | 46 | Software Update Procedure | 72 |
| Shutdown | 47 | Replace Temperature Control Module (TCM) | 72 |
| Flushing | 49 | Parts | 73 |
| Repair | 50 | Electrical Schematics | 93 |
| Before Beginning Repair | 50 | Reactor 2 Repair Spare Parts Reference | 96 |
| Flush Inlet Strainer Screen | 50 | Performance Charts | 97 |
| Change Pump Lubricant | 51 | Technical Specifications | 100 |
| Remove Pump | 52 | Notes | 102 |
| Install Pump | 53 | Graco Extended Warranty for Reactor® 2 Components | 103 |
| Repair Drive Housing | 54 | | |
| Repair Electric Motor | 57 | | |
| Repair Circuit Breaker Module | 58 | | |
| Replace Fluid Inlet Sensor | 59 | | |

Warnings

The following warnings are for the setup, use, grounding, maintenance, and repair of this equipment. The exclamation point symbol alerts you to a general warning and the hazard symbols refer to procedure-specific risks. When these symbols appear in the body of this manual or on warning labels, refer back to these Warnings. Product-specific hazard symbols and warnings not covered in this section may appear throughout the body of this manual where applicable.

|  WARNING | |
|--|--|
|   | <p>ELECTRIC SHOCK HAZARD</p> <p>This equipment must be grounded. Improper grounding, setup, or usage of the system can cause electric shock.</p> <ul style="list-style-type: none"> • Turn off and disconnect power at main switch before disconnecting any cables and before servicing or installing equipment. • Connect only to grounded power source. • All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations. • Do not expose to rain. Store indoors. |
|  | <p>TOXIC FLUID OR FUMES</p> <p>Toxic fluids or fumes can cause serious injury or death if splashed in the eyes or on skin, inhaled or swallowed.</p> <ul style="list-style-type: none"> • Read Safety Data Sheet (SDS) for handling instructions and to know the specific hazards of the fluids you are using, including the effects of long-term exposure. • When spraying, servicing equipment, or when in the work area, always keep work area well ventilated and always wear appropriate personal protective equipment. See Personal Protective Equipment warnings in this manual. • Store hazardous fluid in approved containers, and dispose of it according to applicable guidelines. |
|  | <p>PERSONAL PROTECTIVE EQUIPMENT</p> <p>Always wear appropriate personal protective equipment and cover all skin when spraying, servicing equipment, or when in the work area. Protective equipment helps prevent serious injury, including long-term exposure; inhalation of toxic fumes, mists or vapors; allergic reaction; burns; eye injury and hearing loss. This protective equipment includes but is not limited to:</p> <ul style="list-style-type: none"> • A properly fitting respirator, which may include a supplied-air respirator, chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. • Protective eyewear and hearing protection. |

|  <h1 style="margin: 0;">WARNING</h1> | |
|--|---|
|    | <p>SKIN INJECTION HAZARD</p> <p>High-pressure fluid from gun, hose leaks, or ruptured components will pierce skin. This may look like just a cut, but it is a serious injury that can result in amputation. Get immediate surgical treatment.</p> <ul style="list-style-type: none"> • Do not spray without tip guard and trigger guard installed. • Engage trigger lock when not spraying. • Do not point gun at anyone or at any part of the body. • Do not put your hand over the spray tip. • Do not stop or deflect leaks with your hand, body, glove, or rag. • Follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing equipment. • Tighten all fluid connections before operating the equipment. • Check hoses and couplings daily. Replace worn or damaged parts immediately. |
|     | <p>FIRE AND EXPLOSION HAZARD</p> <p>Flammable fumes, such as solvent and paint fumes, in work area can ignite or explode. To help prevent fire and explosion:</p> <ul style="list-style-type: none"> • Use equipment only in well ventilated area. • Eliminate all ignition sources; such as pilot lights, cigarettes, portable electric lamps, and plastic drop cloths (potential static arc). • Keep work area free of debris, including solvent, rags and gasoline. • Do not plug or unplug power cords, or turn power or light switches on or off when flammable fumes are present. • Ground all equipment in the work area. See Grounding instructions. • Use only grounded hoses. • Hold gun firmly to side of grounded pail when triggering into pail. Do not use pail liners unless they are antistatic or conductive. • Stop operation immediately if static sparking occurs or you feel a shock. Do not use equipment until you identify and correct the problem. • Keep a working fire extinguisher in the work area. |
|    | <p>THERMAL EXPANSION HAZARD</p> <p>Fluids subjected to heat in confined spaces, including hoses, can create a rapid rise in pressure due to the thermal expansion. Over-pressurization can result in equipment rupture and serious injury.</p> <ul style="list-style-type: none"> • Open a valve to relieve the fluid expansion during heating. • Replace hoses proactively at regular intervals based on your operating conditions. |

|  <h1 style="margin: 0;">WARNING</h1> | |
|--|--|
|  | <p>PRESSURIZED ALUMINUM PARTS HAZARD</p> <p>Use of fluids that are incompatible with aluminum in pressurized equipment can cause serious chemical reaction and equipment rupture. Failure to follow this warning can result in death, serious injury, or property damage.</p> <ul style="list-style-type: none"> • Do not use 1,1,1-trichloroethane, methylene chloride, other halogenated hydrocarbon solvents or fluids containing such solvents. • Many other fluids may contain chemicals that can react with aluminum. Contact your material supplier for compatibility. |
|   | <p>PLASTIC PARTS CLEANING SOLVENT HAZARD</p> <p>Many solvents can degrade plastic parts and cause them to fail, which could cause serious injury or property damage.</p> <ul style="list-style-type: none"> • Use only compatible water-based solvents to clean plastic structural or pressure-containing parts. • See Technical Data in this and all other equipment instruction manuals. Read fluid and solvent manufacturer's MSDSs and recommendations. |
|   | <p>EQUIPMENT MISUSE HAZARD</p> <p>Misuse can cause death or serious injury.</p> <ul style="list-style-type: none"> • Do not operate the unit when fatigued or under the influence of drugs or alcohol. • Do not exceed the maximum working pressure or temperature rating of the lowest rated system component. See Technical Data in all equipment manuals. • Use fluids and solvents that are compatible with equipment wetted parts. See Technical Data in all equipment manuals. Read fluid and solvent manufacturer's warnings. For complete information about your material, request MSDS from distributor or retailer. • Do not leave the work area while equipment is energized or under pressure. • Turn off all equipment and follow the Pressure Relief Procedure when equipment is not in use. • Check equipment daily. Repair or replace worn or damaged parts immediately with genuine manufacturer's replacement parts only. • Do not alter or modify equipment. Alterations or modifications may void agency approvals and create safety hazards. • Make sure all equipment is rated and approved for the environment in which you are using it. • Use equipment only for its intended purpose. Call your distributor for information. • Route hoses and cables away from traffic areas, sharp edges, moving parts, and hot surfaces. • Do not kink or over bend hoses or use hoses to pull equipment. • Keep children and animals away from work area. • Comply with all applicable safety regulations. |
|   | <p>MOVING PARTS HAZARD</p> <p>Moving parts can pinch, cut or amputate fingers and other body parts.</p> <ul style="list-style-type: none"> • Keep clear of moving parts. • Do not operate equipment with protective guards or covers removed. • Pressurized equipment can start without warning. Before checking, moving, or servicing equipment, follow the Pressure Relief Procedure and disconnect all power sources. |



WARNING



BURN HAZARD


Equipment surfaces and fluid that is heated can become very hot during operation. To avoid severe burns:

- Do not touch hot fluid or equipment.

Important Isocyanate Information

Isocyanates (ISO) are catalysts used in two component materials.

Isocyanate Conditions




Spraying or dispensing fluids that contain isocyanates creates potentially harmful mists, vapors, and atomized particulates.




- Read and understand the fluid manufacturer’s warnings and Safety Data Sheet (SDS) to know specific hazards and precautions related to isocyanates.
- Use of isocyanates involves potentially hazardous procedures. Do not spray with this equipment unless you are trained, qualified, and have read and understood the information in this manual and in the fluid manufacturer’s application instructions and SDS.
- Use of incorrectly maintained or mis-adjusted equipment may result in improperly cured material, which could cause off gassing and offensive odors. Equipment must be carefully maintained and adjusted according to instructions in the manual.
- To prevent inhalation of isocyanate mists, vapors and atomized particulates, everyone in the work area must wear appropriate respiratory protection. Always wear a properly fitting respirator, which may include a supplied-air respirator. Ventilate the work area according to instructions in the fluid manufacturer’s SDS.
- Avoid all skin contact with isocyanates. Everyone in the work area must wear chemically impermeable gloves, protective clothing and foot coverings as recommended by the fluid manufacturer and local regulatory authority. Follow all fluid manufacturer recommendations, including those regarding handling of contaminated clothing. After spraying, wash hands and face before eating or drinking.
- Hazard from exposure to isocyanates continues after spraying. Anyone without appropriate personal protective equipment must stay out of the work area during application and after application for the time period specified by the fluid manufacturer. Generally this time period is at least 24 hours.
- Warn others who may enter work area of hazard from exposure to isocyanates. Follow the recommendations of the fluid manufacturer and local regulatory authority. Posting a placard such as the following outside the work area is recommended:



Material Self-Ignition

| | | | | |
|--|---|--|--|--|
|  |  | | | |
| Some materials may become self-igniting if applied too thick. Read material manufacturer's warnings and SDS. | | | | |

Keep Components A and B Separate

| | | | | |
|--|---|---|--|--|
|  |  |  | | |
| <p>Cross-contamination can result in cured material in fluid lines which could cause serious injury or damage to equipment. To prevent cross-contamination:</p> <ul style="list-style-type: none"> • Never interchange component A and component B wetted parts. • Never use solvent on one side if it has been contaminated from the other side. | | | | |

Changing Materials

| | | | | |
|--|--|--|--|--|
| NOTICE | | | | |
| <p>Changing the material types used in your equipment requires special attention to avoid equipment damage and downtime.</p> <ul style="list-style-type: none"> • When changing materials, flush the equipment multiple times to ensure it is thoroughly clean. • Always clean the fluid inlet strainers after flushing. • Check with your material manufacturer for chemical compatibility. • When changing between epoxies and urethanes or polyureas, disassemble and clean all fluid components and change hoses. Epoxies often have amines on the B (hardener) side. Polyureas often have amines on the B (resin) side. | | | | |

Moisture Sensitivity of Isocyanates

Exposure to moisture (such as humidity) will cause ISO to partially cure, forming small, hard, abrasive crystals that become suspended in the fluid. Eventually a film will form on the surface and the ISO will begin to gel, increasing in viscosity.

| | | | | |
|---|--|--|--|--|
| NOTICE | | | | |
| <p>Partially cured ISO will reduce performance and the life of all wetted parts.</p> <ul style="list-style-type: none"> • Always use a sealed container with a desiccant dryer in the vent, or a nitrogen atmosphere. Never store ISO in an open container. • Keep the ISO pump wet cup or reservoir (if installed) filled with appropriate lubricant. The lubricant creates a barrier between the ISO and the atmosphere. • Use only moisture-proof hoses compatible with ISO. • Never use reclaimed solvents, which may contain moisture. Always keep solvent containers closed when not in use. • Always lubricate threaded parts with an appropriate lubricant when reassembling. | | | | |

NOTE: The amount of film formation and rate of crystallization varies depending on the blend of ISO, the humidity, and the temperature.

Foam Resins with 245 fa Blowing Agents

Some foam blowing agents will froth at temperatures above 90°F (33°C) when not under pressure, especially if agitated. To reduce frothing, minimize preheating in a circulation system.

Models

Reactor 2 E-30 and E-30 Elite

All elite systems include fluid inlet pressure and temperature sensors, Graco InSite™, and Xtreme-Wrap 50 ft (15 m) head hose. For part numbers, see [Accessories, page 11](#)

| Model | E-30 Model | | | | | | E-30 Elite Model | | | | | |
|---|--------------------------|---------------------------|---------------------------|--------------------------|---------------------------|---------------------------|--------------------------|---------------------------|---------------------------|--------------------------|---------------------------|---------------------------|
| | 10 kW | | | 15 kW | | | 10 kW | | | 15kW | | |
| Proportioner ★ | 272010 | | | 272011 | | | 272110 | | | 272111 | | |
| Maximum Fluid Working Pressure psi (MPa, bar) | 2000 (14, 140) | | | 2000 (14, 140) | | | 2000 (14, 140) | | | 2000 (14, 140) | | |
| Approximate Output per Cycle (A+B) gal. (liter) | 0.0272 (0.1034) | | | 0.0272 (0.1034) | | | 0.0272 (0.1034) | | | 0.0272 (0.1034) | | |
| Max Flow Rate lb/min (kg/min) | 30 (13.5) | | | 30 (13.5) | | | 30 (13.5) | | | 30 (13.5) | | |
| Total System Load † ♦(Watts) | 17,900 | | | 23,000 | | | 17,900 | | | 23,000 | | |
| Configurable Voltage Phase ♦ | 200– 240 VAC 1Ø | 200– 240 VAC 3ØΔ | 350– 415 VAC 3ØY | 200– 240 VAC 1Ø | 200– 240 VAC 3ØΔ | 350– 415 VAC 3ØY | 200– 240 VAC 1Ø | 200– 240 VAC 3ØΔ | 350– 415 VAC 3ØY | 200– 240 VAC 1Ø | 200– 240 VAC 3ØΔ | 350– 415 VAC 3ØY |
| Full Load Peak Current* | 78 | 50 | 34 | 100 | 62 | 35 | 78 | 50 | 34 | 100 | 62 | 35 |

| | | | | | | | | |
|---|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Fusion AP Package ✖ <i>(Gun Part No.)</i> | AP2010 <i>(246102)</i> | AH2010 <i>(246102)</i> | AP2011 <i>(246102)</i> | AH2011 <i>(246102)</i> | AP2110 <i>(246102)</i> | AH2110 <i>(246102)</i> | AP2111 <i>(246102)</i> | AH2111 <i>(246102)</i> |
| Fusion CS Package ✖ <i>(Gun Part No.)</i> | CS2010 <i>(CS02RD)</i> | CH2010 <i>(CS02RD)</i> | CS2011 <i>(CS02RD)</i> | CH2011 <i>(CS02RD)</i> | CS2110 <i>(CS02RD)</i> | CH2110 <i>(CS02RD)</i> | CS2111 <i>(CS02RD)</i> | CH2111 <i>(CS02RD)</i> |
| Probler P2 Package ✖ <i>(Gun Part No.)</i> | P22010 <i>(GCP2R2)</i> | PH2010 <i>(GCP2R2)</i> | P22011 <i>(GCP2R2)</i> | PH2011 <i>(GCP2R2)</i> | P22110 <i>(GCP2R2)</i> | PH2110 <i>(GCP2R2)</i> | P22111 <i>(GCP2R2)</i> | PH2111 <i>(GCP2R2)</i> |
| Heated Hose 50 ft (15 m) 24K240 (scuff guard) 24Y240 (Xtreme-Wrap) | 24K240 | 24K240 | 24K240 | 24K240 | 24Y240 | 24Y240 | 24Y240 | 24Y240 |
| | Qty: 1 | Qty: 5 | Qty: 1 | Qty: 5 | Qty: 1 | Qty: 5 | Qty: 1 | Qty: 5 |
| Heated Whip Hose 10 ft (3 m) | 246050 | | 246050 | | 246050 | | 246050 | |
| Graco Insite™ | | | | | ✓ | | ✓ | |
| Fluid Inlet Sensors (2) | | | | | ✓ | | ✓ | |

- * Full load amps with all devices operating at maximum capabilities. Fuse requirements at various flow rates and mix chamber sizes may be less.
- † Total system watts used by system, based on maximum heated hose length for each unit.
 - E-30 and E-XP2 series: 310 ft (94.5 m) maximum heated hose length, including whip hose.
- ★ See [Approvals, page 11](#).

- ✖ Packages include gun, heated hose, and whip hose. Elite packages also include Graco InSite and fluid inlet sensors.
- ♦ Low line input voltage will reduce power available and heaters will not perform at full capacity.

| Voltage Configurations Key | |
|----------------------------|-------|
| Ø | Phase |
| Δ | DELTA |
| Y | WYE |

Reactor 2 E-XP2 and E-XP2 Elite

All elite systems include fluid inlet pressure and temperature sensors, Graco InSite™, and Xtreme-Wrap 50 ft (15 m) head hose. For part numbers, see [Accessories, page 11](#)

| Model | E-XP2 Model | | | E-XP2 Elite Model | | |
|---|-------------------------|--------------------|--------------------|-------------------------|--------------------|--------------------|
| | 15 kW | | | 15 kW | | |
| Proportioner ★ | 272012 | | | 272112 | | |
| Maximum Fluid Working Pressure psi (MPa, bar) | 3500 (24.1, 241) | | | 3500 (24.1, 241) | | |
| Approximate Output per Cycle (A+B) gal. (liter) | 0.0203 (0.0771) | | | 0.0203 (0.0771) | | |
| Max Flow Rate gpm/min (l/min) | 2 (7.6) | | | 2 (7.6) | | |
| Total System Load † ◆ (Watts) | 23,000 | | | 23,000 | | |
| Configurable Voltage Phase ◆ | 200–240 VAC 1Ø | 200–240 VAC 3ØΔ | 350–415 VAC 3ØY | 200–240 VAC 1Ø | 200–240 VAC 3ØΔ | 350–415 VAC 3ØY |
| Full Load Peak Current (amps)* | 100 | 62 | 35 | 100 | 62 | 35 |
| | | | | | | |
| Fusion AP Package ✖ (Gun Part No.) | AP2012 (246100) | | | AP2112 (246100) | | |
| Probler P2 Package ✖ (Gun Part No.) | P22012 (GCP2R0) | | | P22112 (GCP2R0) | | |
| Heated Hose 50 ft (15 m) | 24K241 (scuff guard) | | | 24Y241 (Xtreme-Wrap) | | |
| Heated Whip Hose 10 ft (3 m) | 246055 | | | 246055 | | |
| Graco InSite™ | | | | ✓ | | |
| Fluid Inlet Sensors (2) | | | | ✓ | | |

* Full load amps with all devices operating at maximum capabilities. Fuse requirements at various flow rates and mix chamber sizes may be less.

† Total system watts used by system, based on maximum heated hose length for each unit.

- E-30 and E-XP2 series: 310 ft (94.5 m) maximum heated hose length, including whip hose.

★ See [Approvals, page 11](#).


✖ Packages include gun, heated hose, and whip hose. Elite packages also include Graco InSite and fluid inlet sensors.

◆ Low line input voltage will reduce power available and heaters will not perform at full capacity.

| Voltage Configurations Key | |
|----------------------------|-------|
| Ø | Phase |
| Δ | DELTA |
| Y | WYE |

Approvals

Intertek approvals apply to proportioners without hoses.



Accessories

| Kit Number | Description |
|------------|---|
| 24U315 | Air Manifold Kit (4 outlets) |
| 24U314 | Wheel and Handle Kit |
| 24T280 | Graco InSite Kit |
| 16X521 | Graco InSite Extension cable 24.6 ft (7.5 m) |
| 24N449 | 50 ft (15 m) CAN cable (for remote display module) |
| 24K207 | Fluid Temperature Sensor (FTS) with RTD |
| 24U174 | Remote Display Module Kit |
| 24K337 | Light Tower Kit |
| 15V551 | ADM Protective Covers (10 pack) |
| 15M483 | Remote Display Module Protective Covers (10 pack) |
| 24M174 | Drum Level Sticks |
| 121006 | 150 ft (45 m) CAN cable (for remote display module) |
| 24N365 | RTD Test Cables (to aide resistance measurements) |

Supplied Manuals

The following manuals are shipped with the Reactor 2. Refer to these manuals for detailed equipment information.

Manuals are also available at www.graco.com.

| Manual | Description |
|--------|---|
| 333023 | Reactor 2 E-30 and E-XP2 Operation |
| 333091 | Reactor 2 E-30 and E-XP2 Startup Quick Guide |
| 333092 | Reactor 2 E-30 and E-XP2 Shutdown Quick Guide |

Related Manuals


The following manuals are for accessories used with the Reactor.

Component Manuals in English:

Manuals are available at www.graco.com.




| System Manuals | |
|--------------------------|---|
| 333023 | Reactor 2 E-30 and E-XP2 Operation |
| Displacement Pump Manual | |
| 309577 | Electric Reactor Displacement Pump, Repair-Parts |
| Feed System Manuals | |
| 309572 | Heated Hose, Instructions-Parts |
| 309852 | Circulation and Return Tube Kit, Instructions-Parts |
| 309815 | Feed Pump Kits, Instructions-Parts |
| 309827 | Feed Pump Air Supply Kit, Instructions-Parts |
| Spray Gun Manuals | |
| 309550 | Fusion™ AP Gun |
| 312666 | Fusion™ CS Gun |
| 313213 | Probler® P2 Gun |
| Accessory Manuals | |
| 3A1905 | Feed Pump Shutdown Kit, Instructions-Parts |
| 3A1906 | Light Tower Kit, Instructions-Parts |
| 3A1907 | Remote Display Module Kit, Instructions-Parts |
| 332735 | Air Manifold Kit, Instructions-Parts |
| 332736 | Handle and Wheel Kit, Instructions-Parts |
| 333276 | Graco InSite™ Kit, Instructions-Parts |

Troubleshooting



Troubleshoot Errors

There are three types of errors that can occur. Errors are indicated on the display as well as by the light tower (optional).

| Error | Description |
|--|---|
| Alarms  | A parameter critical to the process has reached a level requiring the system to stop. The alarm needs to be addressed immediately. |
| Deviations  | A parameter critical to the process has reached a level requiring attention, but not sufficient enough to stop the system at this time. |
| Advisories  | A parameter that is not immediately critical to the process. The advisory needs attention to prevent more serious issues in the future. |

See [Error Codes, page 13](#) for causes and solutions to each error code.


To troubleshoot the error:

Error Codes

Note

When an error occurs be sure to determine the code before resetting it. If you forget which error code occurred, see the Errors screen to view the last 200 errors, with date, time, and description.

1. Press the soft key for help with the active error.



Note





Press  or  to return to the previously displayed screen.





2. The QR code screen will be displayed. Scan the QR code with your smartphone to be sent directly to online troubleshooting for the active error code. Otherwise, manually navigate to <http://help.graco.com> and search for the active error.







3. If no internet connection is available, see [Error Codes, page 13](#) for causes and solutions for each error code.



Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------|---------------------------------|--|
| A1NM | MCM |  | Low Motor Current | Loose/broken connection. | Check for loose wire terminations at MCM motor connector. |
| | | | | Bad Motor. | Disconnect motor output connector from MCM. Confirm less than 8 ohms resistance between each pair of motor power leads (M1 to M2, M1 to M3, M2 to M3). If any readings greater than 8 ohms, check motor wiring for damage and/or loose terminations. |
| A4DA | Heater A |  | High Current A | Short circuit in heater wiring. | Check wiring for touching wires. |
| | | | | Bad Heater. | Confirm resistance of heater. Heater resistance should be 18–21 Ω for each heater element, 9–12 Ω combined for 10 kW systems, and 6-8 Ω for 15 kW systems. If out of tolerance, replace heater element. |
| A4DB | Heater B |  | High Current B | Short circuit in heater wiring. | Check wiring for touching wires. |
| | | | | Bad Heater. | Confirm resistance of heater. Heater resistance should be 9-12 Ω for 10 kW systems and 6-8 Ω for 15 kW systems. If out of tolerance, replace heater. |
| A4DH | Hose |  | High Current Hose | Short circuit in hose wiring. | Check continuity of transformer windings. Normal readings are about 0.2Ω on both primary and secondary. If reading is 0Ω replace transformer. |
| | | | | | Check for shorts between the primary winding and the support frame or enclosure. |


| Error | Location | Type | Description | Cause | Solution |
|-------|----------|--|-------------------------|--------------------------------|---|
| A4NM | MCM |  | High Motor Current | Short circuit of motor wiring. | Check wiring to the motor to ensure no bare wires are touching and that no wires are shorted to ground. |
| | | | | Motor will not rotate. | Remove pump gear housings from motor and check that motor shaft rotates freely in direction indicated on motor housing. |
| | | | | Damaged gear train. | Check pump gear trains for damage and repair or replace as necessary. |
| | | | | Chemical pump is stuck. | Repair or replace chemical pump. |
| A7DA | Heater A |  | Unexpected Current A | Shorted TCM | If error cannot be cleared or regenerates consistently, replace module. |
| A7DB | Heater B |  | Unexpected Current B | Shorted TCM | If error cannot be cleared or regenerates consistently, replace module. |
| A7DH | Hose |  | Unexpected Current Hose | Shorted TCM | If error cannot be cleared or regenerates consistently, replace module. |












Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------------|--------------------------------|---|
| A8DA | Heater A |  | No Current A | Tripped circuit breaker. | Visually check circuit breaker for a tripped condition. |
| | | | | Loose/broken connection. | Check heater wiring for loose wires. |
| A8DB | Heater B |  | No Current B | Tripped circuit breaker. | Visually check circuit breaker for a tripped condition. |
| | | | | Loose/broken connection. | Check heater wiring for loose wires. |
| A8DH | Hose |  | No Current Hose | Tripped circuit breaker. | Visually check circuit breaker for a tripped condition. |
| | | | | Loose/broken connection. | Check heater wiring for loose wires. |
| CACM | MCM |  | MCM Communication Error | Module does not have software. | Insert a system token into the ADM module and cycle the power. Wait until the upload is complete before removing the token. |
| | | | | Dial set to wrong position. | Ensure the MCM dial is set to the correct position: 2 for E-30, 3 for E-XP2 |
| | | | | No 24 VDC supply to module. | Green light on each module should be lit. If green light is not lit, check to make sure each CAN cable connection is tight. Verify the power supply is outputting 24 VDC. If not, check power supply wiring. If wiring is okay, replace the power supply. |
| | | | | Loose or broken CAN cable. | Check the CAN cables running between GCA modules and tighten if needed. If the problem still persists move each cable around the connector and watch the flashing yellow light on the GCA modules. If the yellow light stops flashing, replace the CAN cable. |





| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------------|--------------------------------|---|
| CACT | TCM |  | TCM Communication Error | Module does not have software. | Insert a system token into the ADM module and cycle the power. Wait until the upload is complete before removing the token. |
| | | | | No 24 VDC supply to module. | Green light on each module should be lit. If green light is not lit, check to make sure each CAN cable connection is tight. Verify the power supply is outputting 24 VDC. If not, check power supply wiring. If wiring is okay, replace the power supply. |
| | | | | Loose or broken CAN cable. | Check the CAN cables running between GCA modules and tighten if needed. If the problem still persists move each cable around the connector and watch the flashing yellow light on the GCA modules. If the yellow light stops flashing, replace the CAN cable. |
| DADX | MCM |  | Pump Runaway | Flow rate is too large. | Mix chamber too large for system selected. Use mix chamber rated for system. |
| | | | | | Ensure the system has chemical and the feed pumps are operating correctly. |
| | | | | | No material in pumps. Verify pumps are supplying chemical. If necessary, replace or refill drums. |
| | | | | | Inlet ball valves are closed. Open ball valves. |





Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|--------------------|--|--|
| DE0X | MCM |  | Cycle Switch Error | Faulty or missing cycle switch. | Check wiring between cycle switch and MCM, Port 12. |
| | | | | Switch disconnected | Measure resistance between pin 3 and 4 at connector. Normal resistance is 0.10 ohms. |
| | | | | Missing or out of place cycle switch magnet. | Check presence and position of cycle switch magnet on output crank arm. |




| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|----------------------------|---|---|
| EVCH | ADM |  | Manual Hose Mode Enabled | Manual hose mode has been enabled in System Setup screen. | Install a functioning fluid temperature sensor (FTS) on the hose. Manual hose mode will automatically turn off. |
| EAUX | ADM |  | USB Busy | USB drive has been inserted to the ADM. | Do not remove USB drive until download/upload is complete. |
| EVUX | ADM |  | USB disabled | USB download/uploads are disabled. | Enable USB download/uploads on the Advanced Setup screen before inserting a USB drive. |
| F9DX | MCM |  | High Pressure/Flow Cutback | Mix chamber is too large for set pressure. | Reference the pressure flow curves and select a tip size that is the correct size for the set pressure. |
| H2MA | Heater A |  | Low Frequency A | Line frequency is below 45 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| H2MB | Heater B |  | Low Frequency B | Line frequency is below 45 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| H2MH | Hose |  | Low Frequency Hose | Line frequency is below 45 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| H3MA | Heater A |  | High Frequency A | Line frequency is above 65 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| H3MB | Heater B |  | High Frequency B | Line frequency is above 65 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| H3MH | Hose |  | High Frequency Hose | Line frequency is above 65 Hz | Ensure line frequency of incoming power is between 45 and 65 Hz. |
| K8NM | MCM |  | Locked Rotor Motor | Motor will not rotate. | Remove pump gear housings from motor and check that motor shaft rotates freely in direction indicated on motor housing. |
| | | | | Damaged gear train. | Check motor/pump gear trains for damage and repair or replace as necessary. |
| | | | | Chemical pump is stuck. | Repair or replace chemical pump. |




Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|--|---|
| L1AX | ADM |  | Low Chemical Level A | Low material level. | Refill material and update drum level on ADM Maintenance screen. Alarm can be disabled on the System Setup screen. |
| L1BX | ADM |  | Low Chemical Level B | Low material level. | Refill material and update drum level on ADM Maintenance screen. Alarm can be disabled on the System Setup screen. |
| MMUX | USB |  | Maintenance Due - USB | USB logs have reached a level where data loss will occur if logs are not downloaded. | Insert a USB drive into the ADM and download all logs. |
| P0AX | MCM |  | Pressure Imbalance A High | Pressure difference between A and B material is greater than the defined value. | Ensure material flow is equally restricted on both material lines. |
| | | | | Pressure imbalance is defined too low. | Ensure that the pressure imbalance value, on the System Setup screen, is at an acceptable maximum pressure to prevent unnecessary alarms and abort dispenses. |
| | | | | Out of material. | Fill tanks with material |
| | | | | Fluid leaking from heater inlet rupture disk. | Check if heater and PRESSURE RELIEF/SPRAY valve are plugged. Clear. Replace rupture disk. Do not replace with a pipe plug. |
| | | | | Feed system defective. | Check feed pump and hoses for blockage. Check that feed pumps have correct air pressure. |



| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|---|---|
| P0BX | MCM |  | Pressure Imbalance B High | Pressure difference between A and B material is greater than the defined value. | Ensure material flow is equally restricted on both material lines. |
| | | | | Pressure imbalance is defined too low. | Ensure that the pressure imbalance value, on the System Setup screen, is at an acceptable maximum pressure to prevent unnecessary alarms and abort dispenses. |
| | | | | Out of material. | Fill tanks with material |
| | | | | Fluid leaking from heater inlet rupture disk. | Check if heater and PRESSURE RELIEF/SPRAY valve are plugged. Clear. Replace rupture disk. Do not replace with a pipe plug. |
| | | | | Feed system defective. | Check feed pump and hoses for blockage. Check that feed pumps have correct air pressure. |
| P1FA | MCM |  | Low Inlet Pressure A | Inlet pressure lower than defined value. | Ensure that inlet pressure to the pump is sufficient. |
| | | | | Value defined too high. | Ensure that the low pressure alarm level defined on the System Setup screen is acceptable. |
| P1FB | MCM |  | Low Inlet Pressure B | Inlet pressure lower than defined value. | Ensure that inlet pressure to the pump is sufficient. |
| | | | | Value defined too high. | Ensure that the low pressure alarm level defined on the System Setup screen is acceptable. |
| P2FA | MCM |  | Low Inlet Pressure A | Inlet pressure lower than defined value. | Ensure that inlet pressure to the pump is sufficient. |
| | | | | Value defined too high. | Ensure that the low pressure alarm level defined on the System Setup screen is acceptable. |



Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|--|----------------------|--|--|
| P2FB | MCM |  | Low Inlet Pressure B | Inlet pressure lower than defined value. | Ensure that inlet pressure to the pump is sufficient. |
| | | | | Value defined too high. | Ensure that the low pressure alarm level defined on the System Setup screen is acceptable. |
| P4AX | MCM |  | High Pressure A | System pressurized before allowing heat to reach setpoint. | Pressure in the hose and pumps will increase as the system heats up. Turn on heat and allow all zones to reach the temperature setpoint before turning on the pumps. |
| | | | | Bad pressure transducer. | Verify the ADM pressure reading and the analog gauges at the manifold. |
| | | | | E-XP2 system configured as E-30. | Alarm level is lower for E-30 than for E-XP2. Ensure dial on MCM is set to position "3" for E-XP2. |
| P4BX | MCM |  | High Pressure B | System pressurized before allowing heat to reach setpoint. | Pressure in the hose and pumps will increase as the system heats up. Turn on heat and allow all zones to reach the temperature setpoint before turning on the pumps. |
| | | | | Bad pressure transducer. | Verify the ADM pressure reading and the analog gauges at the manifold. |
| | | | | E-XP2 system configured as E-30. | Alarm level is lower for E-30 than for E-XP2. Ensure dial on MCM is set to position "3" for E-XP2. |





| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------------------|------------------------------|---|
| P6AX | MCM |  | Pressure Sensor Error A | Loose/bad connection. | Check to ensure the pressure transducer is properly installed and all wires are properly connected. |
| | | | | Bad sensor. | Check if the error follows the transducer. Disconnect transducer cables from the MCM (connectors 6 and 7). Reverse A and B connections and check if the errors follows. If the error follows the transducer, replace the pressure transducer. |
| P6BX | MCM |  | Pressure Sensor Error B | Loose/bad connection. | Check to ensure the pressure transducer is properly installed and all wires are properly connected. |
| | | | | Bad sensor. | Check if the error follows the transducer. Disconnect transducer cables from the MCM (connectors 6 and 7). Reverse A and B connections and check if the errors follows. If the error follows the transducer, replace the pressure transducer. |
| P6FA | MCM |  | Pressure Sensor Error Inlet A | Inlet sensors not installed. | If inlet sensors are not installed, inlet sensors should be disabled on the System Setup screen. |
| | | | | Loose/bad connection. | Check to ensure inlet sensor is properly installed and all wires are properly connected. |
| | | | | Bad sensor. | Check if the error follows the inlet sensor. Disconnect inlet sensor cables from the MCM (connectors 8 and 9). Reverse A and B connections and check if the errors follows. If the error follows the sensor, replace the inlet sensor. |






Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------------------|---|--|
| P6FB | MCM |  | Pressure Sensor Error Inlet B | Inlet sensors not installed. | If inlet sensors are not installed, inlet sensors should be disabled on the System Setup screen. |
| | | | | Loose/bad connection. | Check to ensure inlet sensor is properly installed and all wires are properly connected. |
| | | | | Bad sensor. | Check if the error follows the inlet sensor. Disconnect inlet sensor cables from the MCM (connectors 8 and 9). Reverse A and B connections and check if the errors follows. If the error follows the sensor, replace the inlet sensor. |
| P7AX | MCM |  | Pressure Imbalance A High | Pressure difference between A and B material is greater than the defined value. | Ensure material flow is equally restricted on both material lines. |
| | | | | Pressure imbalance is defined too low. | Ensure that the pressure imbalance value, on the System Setup screen, is at an acceptable maximum pressure to prevent unnecessary alarms and abort dispenses. |
| | | | | Out of material. | Fill tanks with material |
| | | | | Fluid leaking from heater inlet rupture disk. | Check if heater and PRESSURE RELIEF/SPRAY valve are plugged. Clear. Replace rupture disk. Do not replace with a pipe plug. |
| | | | | Feed system defective. | Check feed pump and hoses for blockage. Check that feed pumps have correct air pressure. |




| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|---|--|
| P7BX | MCM |  | Pressure Imbalance B High | Pressure difference between A and B material is greater than the defined value. | Ensure material flow is equally restricted on both material lines. |
| | | | | Pressure imbalance is defined too low. | Ensure that the pressure imbalance value, on the System Setup screen, is at an acceptable maximum pressure to prevent unnecessary alarms and abort dispenses. |
| | | | | Out of material. | Fill tanks with material |
| | | | | Fluid leaking from heater inlet rupture disk. | Check if heater and PRESSURE RELIEF/SPRAY valve are plugged. Clear. Replace rupture disk. Do not replace with a pipe plug. |
| | | | | Feed system defective. | Check feed pump and hoses for blockage. Check that feed pumps have correct air pressure. |
| T2DA | Heater A |  | Low Temperature A | Flow is too high at current setpoint. | Use a smaller mix chamber that is rated for the unit in use. If recirculating, decrease flow or decrease temperature setpoint. |
| | | | | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Bad heater rod or loose heater wire. | Confirm resistance of heater. Heater resistance should be 9-12 Ω for 10 kW systems and 6-8 Ω for 15 kW systems. If out of tolerance, check for loose heater rod wire(s). Reconnect wires or replace heater rod if necessary. |



Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------------|---|--|
| T2DB | Heater B |  | Low Temperature B | Flow is too high at current setpoint. | Use a smaller mix chamber that is rated for the unit in use. If recirculating, decrease flow or decrease temperature setpoint. |
| | | | | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Bad heater rod or loose heater wire. | Confirm resistance of heater. Heater resistance should be 9-12 Ω for 10 kW systems and 6-8 Ω for 15 kW systems. If out of tolerance, check for loose heater rod wire(s). Reconnect wires or replace heater rod if necessary. |
| T2DH | Hose |  | Low Temperature Hose | Flow is too high at current setpoint. | Use a smaller mix chamber that is rated for the unit in use. If recirculating, decrease flow or decrease temperature setpoint. |
| | | | | Cold chemical in unheated portion of system passed hose FTS at startup. | Recirculate heated chemical back to drum in cold conditions before startup. |
| T2FA | MCM |  | Low Temperature Inlet A | Inlet fluid temperature is below the defined level. | Recirculate fluid through heaters until inlet fluid temperature is above defined error level. |
| | | | | | Increase the low temperature deviation level on the System Setup screen. |
| T2FB | MCM |  | Low Temperature Inlet B | Inlet fluid temperature is below the defined level. | Recirculate fluid through heaters until inlet fluid temperature is above defined error level. |
| | | | | | Increase the low temperature deviation level on the System Setup screen. |



| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|---|---|
| T3CH | Hose |  | Hose Cutback | Hose current has been reduced because hose has been drawing current for an extended period. | Hose setpoint higher than A and B setpoints. Decrease hose setpoint. |
| | | | | | Hose FTS is in a colder environment than the rest of the hose. Expose FTS to the same environment as the rest of the hose. |
| T3CT | TCM |  | TCM Cutback | High ambient temperature. | Ensure ambient temperature is below 120°F(48°C) before using the system. |
| | | | | Enclosure fan not operating. | Ensure fan in electrical enclosure is spinning. If it is not, check fan wiring or replace fan. |
| | | | | Module fan not operating. | If a TCM fan error (WMIO) has occurred, fan inside the module is not working properly. Check TCM fan for debris and clear with forced air if necessary. |
| T3NM | MCM |  | Motor Temperature Cutback | Motor is operating outside of the pressure flow curve. | The system is running at a lower setpoint to preserve motor life. Run the system at a lower duty cycle or with a smaller mix chamber. |
| | | | | High ambient temperature | Ensure ambient temperature is below 120° F (48° C) before using the system. |
| T3CM | MCM |  | MCM Temperature Cutback | Motor control temperature is too high. | Ensure ambient temperature is below 120°F(48°C). Verify that all fans are working. |
| T4CM | MCM |  | High Temperature MCM | High ambient temperature. | Ensure ambient temperature is below 120°F(48°C) before using the system. |
| | | | | Enclosure fan not operating. | Ensure fan in electrical enclosure is spinning. If it is not, check fan wiring or replace fan. |


Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|----------------------|--|---|
| T4CT | TCM |  | High Temperature TCM | High ambient temperature. | Ensure ambient temperature is below 120°F(48°C) before using the system. |
| | | | | Enclosure fan not operating. | Ensure fan in electrical enclosure is spinning. If it is not, check fan wiring or replace fan. |
| | | | | Module fan not operating. | If a TCM fan error (WMIO) has occurred, fan inside the module is not working properly. Check TCM fan for debris and clear with forced air if necessary. |
| T4DA | Heater A |  | High Temperature A | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Flow too high for temperature setpoint, causing temperature overshoots when gun is de-triggered. | Use a smaller mix chamber that is rated for the unit in use. |
| T4DB | Heater B |  | High Temperature B | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Flow too high for temperature setpoint, causing temperature overshoots when gun is de-triggered. | Use a smaller mix chamber that is rated for the unit in use. |




| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|---|--|
| T4DH | Hose |  | High Temperature Hose | Hose portion exposed to an excessive heat source, like hot sun or coiled hose, can pass fluid more than 27°F (15°C) over hose temperature setting to the FTS. | Shade exposed hose from hot sun or expose FTS to same environment when at rest. Uncoil entire hose before heating to avoid self-heating. |
| | | | | Setting the A or B setpoint much higher than hose setpoint can cause fluid more than 27°F (15°C) over hose temperature setting to reach the FTS. | Increase hose setpoint so it is closer to A and B setpoints. |
| T4EA | Heater A |  | High Temperature Switch A | Overtemperature switch sensed a fluid temperature above 230°F (110°C). | Heater was delivered too much power, causing the overtemperature switch to open. RTD is not reading properly. After the heater cools down, replace RTD. Switch closes and the error can be cleared when the heater temperature falls below 190°F (87°C). |
| | | | | Disconnected or loose overtemperature switch cable/connection. | If heater is not actually over temperature, check all wiring and connections between the TCM and the overtemperature switches. |
| | | | | Overtemperature switch failed in the open position. | Replace overtemperature switch. |


Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|---------------------------|--|---|
| T4EB | Heater B |  | High Temperature Switch B | Overtemperature switch sensed a fluid temperature above 230°F (110°C). | Heater was delivered too much power, causing the overtemperature switch to open. RTD is not reading properly. After the heater cools down, replace RTD. Switch closes and the error can be cleared when the heater temperature falls below 190°F (87°C). |
| | | | | Disconnected or loose overtemperature switch cable/connection. | If heater is not actually over temperature, check all wiring and connections between the TCM and the overtemperature switches. |
| | | | | Overtemperature switch failed in the open position. | Replace overtemperature switch. |
| T4NM | MCM |  | High Temperature Motor | Cooling fan is not operating properly. | Check to see that the motor fan is moving. Measure voltage to fan. There should be 24 VDC. If no voltage is measured, check fan wiring. If the fan has voltage but is not moving, replace fan. If necessary use an air hose to blow out around the fan housings and remove any built-up debris. |
| | | | | High ambient temperature. | Ensure ambient temperature is below 120°F(48°C) before using the system. |
| | | | | Motor is operating outside of the pressure flow curve | Run the system at a lower duty cycle or with a smaller mix chamber. |
| | | | | Motor temperature sensor wires are shorted together | Measure resistance between pins 2 and 4 on motor temperature cable connector at MCM, port 2. A reading below 75 ohms indicates a wire short. Replace motor. |





| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|----------------|--|---|
| T6DA | Heater A |  | Sensor Error A | Disconnected or loose RTD cable or connection. | Check all wiring and connection to RTD. |
| | | | | Bad RTD. | Switch the RTD with another and see if the error message follows the RTD. Replace RTD if the error follows the RTD. |








Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|--|-------------------|---|--|
| T6DB | Heater B |  | Sensor Error B | Disconnected or loose RTD cable or connection. | Check all wiring and connection to RTD. |
| | | | | Bad RTD. | Switch the RTD with another and see if the error message follows the RTD. Replace RTD if the error follows the RTD. |
| T6DH | Hose |  | Sensor Error Hose | Disconnected or shorted RTD cable in hose or bad FTS. | Expose each hose RTD connection to check and retighten any loose connector. Measure hose RTD cable and FTS continuity. See Repair Heated Hose, page 66 . Order RTD Test kit 24N365 for measurement. Disconnect hose RTD and use manual hose mode to finish job until repair can be completed. |
| T6DT | TCM |  | Sensor Error TCM | Shorted RTD cable in hose or FTS. | Expose each hose RTD connection to check for exposed and shorted RTD wires. Measure hose RTD cable and FTS continuity. See Repair Heated Hose, page 66 . Order RTD Test kit 24N365 for measurement. Disconnect hose RTD and use manual hose mode to finish job until repair can be completed. |
| | | | | Shorted A or B Heater RTD | If the error still occurs with the hose FTS unplugged, one of the heater RTDs is bad. Unplug the A or B RTD from the TCM. If unplugging an RTD fixes the T6DT error, replace the RTD. |








| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|--------------------|---|---|
| T6NM | MCM |  | Sensor Error Motor | Disconnected or loose motor temperature cable connector | Verify proper cable connection at MCM, port 2. Measure resistance between pins 2 and 4 on motor temperature cable connector. A correct ohm reading will vary greatly with temperature. An open circuit reading indicates a wire break. Replace motor. |






Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|--------------------------|---|--|
| T8DA | Heater A |  | No Temperature Rise A | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Bad heater rod or loose heater wire. | Confirm resistance of heater. Heater resistance should be 9-12 Ω for 10 kW systems and 6-8 Ω for 15 kW systems. If out of tolerance, check for loose heater rod wire(s). Reconnect wires or replace heater rod if necessary. |
| | | | | Started spraying before heater reached operating temperature. | Wait until operating temperature has been reached before spraying or recirculating. |
| T8DB | Heater B |  | No Temperature Rise B | Bad RTD or bad RTD placement against heater. | Swap A and B heater output cables and RTD cables and see if issue follows. If so, replace RTD. |
| | | | | Bad heater rod or loose heater wire. | Confirm resistance of heater. Heater resistance should be 9-12 Ω for 10 kW systems and 6-8 Ω for 15 kW systems. If out of tolerance, check for loose heater rod wire(s). Reconnect wires or replace heater rod if necessary. |
| | | | | Started spraying before heater reached operating temperature. | Wait until operating temperature has been reached before spraying or recirculating. |
| T8DH | Hose |  | No Temperature Rise Hose | Started spraying before heater reached operating temperature. | Wait until operating temperature has been reached before spraying or recirculating. |
| V1CM | MCM |  | Low Voltage MCM | Loose/bad connection or tripped circuit breaker. | Check wiring for loose connection or tripped circuit breaker. |
| | | | | Low incoming line voltage. | Measure voltage at circuit breaker and ensure voltage is greater than 195 VAC. |

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|------------------|--|--|
| V1IT | TCM |  | Low Voltage CAN | Bad 24 VDC power supply. | Check voltage of power supply. Voltage should be 23-25 VDC. If out of tolerance, replace power supply. |
| V2IT | TCM |  | Low Voltage CAN | Bad 24 VDC power supply. | Check voltage of power supply. Voltage should be 23-25 VDC. If out of tolerance, replace power supply. |
| V2MA | TCM |  | Low Voltage A | Loose connection or tripped circuit breaker. | Check wiring for loose connection or tripped circuit breaker. |
| | | | | Low incoming line voltage. | Measure voltage at circuit breaker and ensure voltage is greater than 195 VAC. |
| V2MB | TCM |  | Low Voltage B | Loose connection or tripped circuit breaker. | Check wiring for loose connection or tripped circuit breaker. |
| | | | | Low incoming line voltage. | Measure voltage at circuit breaker and ensure voltage is greater than 195 VAC. |
| V2MH | TCM |  | Low Voltage Hose | Loose connection or tripped circuit breaker. | Check wiring for loose connection or tripped circuit breaker. |
| | | | | Low incoming line voltage. | Measure voltage at circuit breaker and ensure voltage is greater than 195 VAC. |
| V3IT | TCM |  | High Voltage CAN | Bad 24 VDC power supply. | Check voltage of power supply. Voltage should be 23-25 VDC. If out of tolerance, replace power supply. |
| V3MA | TCM |  | High Voltage A | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |

Troubleshooting

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|---|-------------------|------------------------------------|--|
| V3MB | TCM |  | High Voltage B | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |
| V3MH | TCM |  | High Voltage Hose | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |
| V4CM | MCM |  | High Voltage MCM | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |
| V4IT | TCM |  | High Voltage CAN | Bad 24 VDC power supply. | Check voltage of power supply. Voltage should be 23-25 VDC. If out of tolerance, replace power supply. |
| V4MA | TCM |  | High Voltage A | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |
| V4MB | TCM |  | High Voltage B | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |
| V4MH | TCM |  | High Voltage Hose | Incoming line voltage is too high. | Ensure incoming system power is wired properly. Verify voltage at each circuit breaker is between 195 and 264 VAC. |

| Error | Location | Type | Description | Cause | Solution |
|-------|----------|--|-------------------------|--|---|
| WBC0 | MCM |  | Software Version Error | Incorrect software version. | Insert a system token into the ADM module and cycle the power. Wait until the upload is complete before removing the token. |
| | | | | MCM does not have line voltage. | If V1CM also exists, see troubleshooting for V1CM. The software version cannot be read if the MCM does not have line voltage. |
| WMIO | TCM |  | TCM Fan Error | Fan inside TCM is not operating properly. | Check for debris in the TCM fan and clear with forced air if necessary. |
| WSUX | USB |  | Configuration Error USB | A valid configuration file can't be found for the USB. | Inset a system token into the ADM and cycle power. Wait until the lights on the USB port stop flashing before removing token. |
| WXUD | ADM |  | USB Download Error | Log download failed. | Backup and reformat the USB drive. Retry download. |
| WXUU | ADM |  | USB Upload Error | Custom language file failed to upload. | Perform normal USB download and use the new disptext.txt file to upload the custom language. |

System




Before performing any troubleshooting procedures:

1. Relieve Pressure. See [Pressure Relief Procedure, page 46](#).
2. Turn main power switch OFF.
3. Allow equipment to cool.

| Problem | Cause | Solution |
|----------------------------------|---------------------------------|--|
| Reactor ADM does not turn on. | No power. | Turn main power switch ON. |
| | Failed 24 V power supply. | Replace power supply. |
| | Failed surge protector. | Replace surge protector. |
| Electric motor does not operate. | Loose connections. | Check MCM connection 13. |
| | Tripped circuit breaker (CB02). | Reset breaker, see Repair Circuit Breaker Module, page 58 . Check 240VAC at output of breaker. |
| | Shorted windings. | Replace motor, see Repair Electric Motor, page 57 . |
| Electric motor runs erratically. | Failed motor bearing. | Replace motor, see Repair Electric Motor, page 57 . |

| Problem | Cause | Solution |
|--------------------------------------|---|--|
| Cooling fans not working. | Loose wire. | Check. See Electrical Schematics, page 93. |
| | Fan blade obstructed. | Remove obstruction. |
| | Defective fan. | Replace. See Replace Motor Fan, page 60. |
| Pump output low. | Obstructed fluid hose or gun; fluid hose ID too small. | Open, clear; use hose with larger ID. |
| | Worn piston valve or intake valve in displacement pump. | See pump manual. |
| | Pressure setpoint too high. | Reduce setpoint and output will increase. |
| Fluid leak in pump packing nut area. | Worn throat seals. | Replace. See pump manual. |
| No pressure on one side. | Fluid leaking from heater inlet rupture disk (372). | Check if heater and PRESSURE RELIEF/SPRAY valve (SA or SB) are plugged. Clear. Replace rupture disk (372) with a new one; do not replace with a pipe plug. |

Hose Heat System



Before performing any troubleshooting procedures:

1. Relieve Pressure. See [Pressure Relief Procedure, page 46](#).
2. Turn main power switch OFF.
3. Allow equipment to cool.

| Problem | Cause | Solution |
|--|--|---|
| Hose heats but heats slower than usual or it does not reach temperature. | Ambient temperature is too cold. | Relocate hoses to a warmer area or recirculate heated fluid through the hose. |
| | FTS failed or not installed correctly. | Check FTS, see Check RTD Cables and FTS, page 67 . |
| | Low supply voltage. | Verify line voltage. Low line voltage significantly reduces power available to the hose heat system, affecting longer hose lengths. |
| Hose does not maintain temperature while spraying. | A and B setpoints too low. | Increase A and B setpoints. Hose is designed to maintain temperature, not to increase it. |
| | Ambient temperature is too cold. | Increase A and B setpoints to increase fluid temperature and keep it steady. |
| | Flow too high. | Use smaller mix chamber. Decrease pressure. |
| | Hose was not fully preheated. | Wait for hose to heat to correct temperature before spraying. |
| | Low supply voltage. | Verify line voltage. Low line voltage significantly reduces power available to the hose heat system, affecting longer hose lengths. |


| Problem | Cause | Solution |
|------------------------------------|--|--|
| Hose temperature exceeds setpoint. | A and/or B heaters are overheating material. | Check primary heaters for either a RTD problem or a failed element attached to RTD, see Electrical Schematics, page 93 . |
| | Faulty FTS connections. | Verify that all FTS connections are snug and that pins of connectors are clean. Unplug and re-plug RTD wires, cleaning off any debris. |
| | Ambient temperature is too high. | Cover hoses or move to a location with a lower ambient temperature. |
| | Missing or damaged insulation around FTS, causing the hose heat to be ON constantly. | Make sure the hose bundle has adequate insulation evenly covering the entire length and connection joints. |

Troubleshooting

| Problem | Cause | Solution |
|---------------------------|--|--|
| Erratic hose temperature. | Faulty FTS connections. | Verify that all FTS connections are snug and that pins of connectors are clean. Unplug and re-plug FTS wires along length of hose, cleaning off any debris. |
| | FTS not installed correctly. | FTS should be installed close to end of hose in same environment as gun. Verify FTS installation, see Repair Fluid Temperature Sensor (FTS), page 68 . |
| | Missing or damaged insulation around FTS, causing the hose heat to be ON constantly. | Make sure the hose bundle has adequate insulation evenly covering the entire length and connection joints. |
| Hose does not heat. | FTS failed. | Check FTS, see Repair Fluid Temperature Sensor (FTS), page 68 . |
| | FTS not installed correctly. | FTS should be installed close to end of hose in same environment as gun. Verify FTS installation, see Repair Fluid Temperature Sensor (FTS), page 68 . |
| | Loose hose electrical connections. | Check connections. Repair as necessary. |
| | Circuit breakers tripped. | Reset breakers (CB01), see Repair Circuit Breaker Module, page 58 . |
| | Hose zone not turned on. | Turn on hose heat zone. |
| | A and B temperature setpoints too low. | Check. Increase if necessary. |

| Problem | Cause | Solution |
|---|---|--|
| Hoses near Reactor are warm, but hoses downstream are cold. | Shorted connection or failed hose heating element. | With power off, check the hose resistance with and without the whip hose attached. With the whip hose attached, the reading should be less than 3 ohm. Without the whip hose attached, the reading should be OL (open loop). See Check Hose Heat Power Connectors, page 66 . |
| Low hose heat. | A and B temperature setpoints too low. | Increase A and B setpoints. Hose designed to maintain temperature, not increase temperature. |
| | Hose temperature setpoint too low. | Check. Increase if necessary to maintain heat. |
| | Flow too high. | Use smaller mix chamber. Decrease pressure. |
| | Low current; FTS not installed. | Install FTS, see operation manual. |
| | Hose heat zone not turned on long enough to reach setpoint. | Allow hose to heat up, or preheat fluid. |
| | Loose hose electrical connections. | Check connections. Repair as necessary. |
| | Ambient temperature is too low | Relocate hoses to a warmer area or increase A and B setpoints. |

Primary Heater



Before performing any troubleshooting procedures:

1. Relieve Pressure. See [Pressure Relief Procedure, page 46](#).
2. Turn main power switch OFF.
3. Allow equipment to cool.

Problems

Try the recommended solutions in the order given for each problem, to avoid unnecessary repairs. Also, determine that all circuit breakers, switches, and controls are properly set and wiring is correct before assuming there is a problem.

| Problem | Cause | Solution |
|--|------------------------------------|---|
| Primary Heater(s) does not heat. | Heat turned off. | Turn on heat zones. |
| | Temperature control alarm. | Check ADM for error codes. |
| | Signal failure from RTD. | Signal failure from RTD. |
| Control of primary heat is abnormal; high temperature overshoots (T4DA, T4DB) occurs intermittently. | Dirty RTD connections. | Examine RTD cables connected to TCMs. Confirm RTDs are not plugged into opposite heat zone. Unplug and re-plug RTD connectors. Unplug and re-plug RTD connectors. Ensure RTD tip contacts the heater element. |
| | RTD not contacting heater element. | Loosen ferrule nut, push in RTD so tip contacts heater element. Holding RTD tip against heater element, tighten ferrule nut 1/4 turn past tight. |
| | Failed heater element. | See Replace Heater Element, page 62 . |
| | Signal failure from RTD. | See (T6DA, T6DB), Error Codes . |

Graco InSite

| Problem | Cause | Solution |
|--|---|--|
| No module status LEDs are illuminated. | No power to cellular module. | Turn Reactor ON. |
| | | Ensure unit is properly installed. |
| | | Verify 24V at output of the power supply. |
| | | Make sure the M8, 4-pin to M12, 8-pin cable is installed between cellular module and power supply. |
| Has not identified GPS location (green module status LED flashing). | Still identifying location. | Wait a few minutes for the unit to identify the location. |
| | Unable to identify location. In a location where GPS lock cannot occur. Buildings and warehouses often prevent GPS locks. | Move system to a location with a clear view of the sky. |
| | | Use extension cable 16X521 and move cellular module to a location with a clear view of the sky. |
| Has not established cellular connection (orange module status LED flashing). | Still establishing cellular connection. | Wait a few minutes for the unit to establish the connection. |
| | Unable to establish cellular connection. | Move system to a location with cellular service to establish cellular connection. |
| | | Use extension cable 16X521 and move cellular module to a location with a clear view of the sky. |
| Cannot view data for my unit(s) on website. | Graco InSite unit has not been activated. | Activate unit. See Registering and Activating the Graco InSite section. |
| Temperature data not displayed on website. | Reactor temperature measurement is not working. | See System troubleshooting section. |
| Hose zone temperature data not displayed on website. | The RTD or thermocouple is not correctly installed on the hose or is broken. | See RTD or Thermocouple repair section. |
| Pressure data not displayed on website. | Reactor pressure measurement is not working. | See System troubleshooting section. |

Pressure Relief Procedure




Follow the Pressure Relief Procedure whenever you see this symbol.



This equipment stays pressurized until pressure is manually relieved. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing equipment.

The Fusion AP gun is shown.

1. Relieve pressure in gun and perform gun shutdown procedure. See gun manual.
2. Close gun fluid inlet valves A and B.




3. Shut off feed pumps and agitator, if used.

4. Route fluid to waste containers or supply tanks. Turn PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE RELIEF/CIRCULATION




Ensure gauges drop to 0.



5. Engage gun piston safety lock.



6. Disconnect gun air line and remove gun fluid manifold.



Shutdown



Shutdown system to avoid electric shock. All electrical wiring must be done by a qualified electrician and comply with all local codes and regulations. To help prevent serious injury from pressurized fluid, such as skin injection, splashing fluid and moving parts, follow the Pressure Relief Procedure when you stop spraying and before cleaning, checking, or servicing equipment.


NOTICE

Proper system setup, startup, and shutdown procedures are critical to electrical equipment reliability. The following procedures ensure steady voltage. Failure to follow these procedures will cause voltage fluctuations that can damage electrical equipment and void the warranty.


1. Press  to stop the pumps.





2. Turn off all heat zones.




3. Relieve pressure. See [Pressure Relief Procedure, page 46](#).



4. Press  to park the Component A Pump. The park operation is complete when green dot goes out. Verify the park operation is complete before moving to next step.




5. Press  to deactivate the system.





6. Turn off the air compressor, air dryer, and breathing air.




7. Turn main power switch OFF.




| | | | |
|--|---|--|--|
|  |  | | |
| To prevent electric shock do not remove any shrouds or open the electrical enclosure door. | | | |

Shutdown


8. Close all fluid supply valves.



9. Engage gun piston safety lock then close fluid inlet valves A and B.






Fusion





Probler

Flushing

| | | | | | |
|--|---|---|--|--|--|
|  |  |  | | | |
| <p>To avoid fire and explosion:</p> <ul style="list-style-type: none"> • Flush equipment only in a well-ventilated area. • Do not turn on heaters until fluid lines are clear of solvent. • Flush out old fluid with new fluid, or flush out old fluid with a compatible solvent before introducing new fluid. • Use the lowest possible pressure when flushing. • All wetted parts are compatible with common solvents. Use only moisture-free solvents. | | | | | |

To flush feed hoses, pumps, and heaters separately from heated hoses, set PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE



RELIEF/CIRCULATION . Flush through bleed lines (N).



To flush entire system, circulate through gun fluid manifold (with manifold removed from gun).

To prevent moisture from reacting with isocyanate, always leave the system filled with a moisture-free plasticizer or oil. Do not use water. Never leave the system dry. See [Important Isocyanate Information](#).

Repair

| | | | | | |
|--|---|--|--|--|--|
|  |  | | | | |
| <p>Repairing this equipment requires access to parts that may cause electric shock or other serious injury if work is not performed properly. Be sure to shut off all power to equipment before repairing.</p> | | | | | |

Before Beginning Repair

| |
|---|
| NOTICE |
| <p>Proper system setup, startup, and shutdown procedures are critical to electrical equipment reliability. The following procedures ensure steady voltage. Failure to follow these procedures will cause voltage fluctuations that can damage electrical equipment and void the warranty.</p> |

1. Flush if necessary. See [Flushing, page 49](#).
2. See [Shutdown, page 47](#).

Flush Inlet Strainer Screen

| | | | | | |
|---|---|---|--|--|--|
|  |  |  | | | |
|---|---|---|--|--|--|

The inlet strainers filter out particles that can plug the pump inlet check valves. Inspect the screens daily as part of the startup routine, and clean as required.

Isocyanate can crystallize from moisture contamination or from freezing. If the chemicals used are clean and proper storage, transfer, and operating procedures are followed, there should be minimal contamination of the A-side screen.

Note

Clean the A-side screen only during daily startup. This minimizes moisture contamination by immediately flushing out any isocyanate residue at the start of dispensing operations.

1. Close the fluid inlet valve on the y-strainer inlet and shut off the appropriate feed pump. This prevents material from being pumped while cleaning the screen.
2. Place a container under the strainer base to catch drain off when removing the strainer plug (C).
3. Remove the screen (A) from the strainer manifold. Thoroughly flush the screen with compatible solvent and shake it dry. Inspect the screen. No more than 25% of the mesh should be restricted. If more than 25% of the mesh is blocked, replace the screen. Inspect the o—ring (B) and replace as required.
4. Ensure the pipe plug (D) is screwed into the strainer plug (C). Install the strainer plug with the screen (A) and o—ring (B) in place and tighten. Do not overtighten. Let the gasket make the seal.
5. Open the fluid inlet valve, ensure that there are no leaks, and wipe the equipment clean. Proceed with operation.




Figure 1

Change Pump Lubricant

Check the condition of the ISO pump lubricant daily. Change the lubricant if it becomes a gel, its color darkens, or it becomes diluted with isocyanate.


Gel formation is due to moisture absorption by the pump lubricant. The interval between changes depends on the environment in which the equipment is operating. The pump lubrication system minimizes exposure to moisture, but some contamination is still possible.

Lubricant discoloration is due to continual seepage of small amounts of isocyanate past the pump packings during operation. If the packings are operating properly, lubricant replacement due to discoloration should not be necessary more often than every 3 or 4 weeks.

To change pump lubricant:

1. Follow [Pressure Relief Procedure, page 46](#).
2. Lift the lubricant reservoir (R) out of the bracket and remove the container from the cap. Holding the cap over a suitable container, remove the check valve and allow the lubricant to drain. Reattach the check valve to the inlet hose.
3. Drain the reservoir and flush it with clean lubricant.
4. When the reservoir is flushed clean, fill with fresh lubricant.



5. Thread the reservoir onto the cap assembly and place it in the bracket.
6. Manually prime the ISO pump. Plug the small vent hole (H) between the tube grommets while squeezing the bottle to force the lubricant up the feed tube. Repeat until the fluid level reaches the ISO pump to force the air out.



Pump Lubrication System
Figure 2




7. Verify that the ISO pump is operating correctly by feeling the pulsation in the return tube during normal proportioner pump operation.
8. Ensure the vent hole stays open.

Remove Pump

| | | | | | |
|---|---|--|--|--|--|
|  |  | | | | |
| <p>Pump rod and connecting rod move during operation. Moving parts can cause serious injury such as pinching or amputation. Keep hands and fingers away from connecting rod during operation.</p> | | | | | |


Note


See manual 309577 for pump repair instructions.


1. Press  to stop the pumps.
2. Turn off heat zones.
3. Flush pump.
4. Press  to park the pumps in the down position.
5. Press  to deactivate the system.
6. Turn main power switch off.



7. Shut off both feed pumps. Close all fluid supply valves.



8. Route fluid to waste containers or supply tanks. Turn PRESSURE RELIEF/SPRAY valves (SA, SB) to PRESSURE RELIEF/CIRCULATION . Ensure gauges drop to 0.




Note

Use drop cloth or rags to protect Reactor and surrounding areas from spills.

Note

Steps 9–11 apply to pump A. To disconnect pump B, go to steps 12 and 13.

9. Disconnect fittings at fluid inlet (C) and outlet (D). Also disconnect steel outlet tube from heater inlet.
10. Disconnect tubes (T). Remove both tube fittings (U) from wet-cup.
11. Loosen locknut (G) by hitting firmly with a non-sparking hammer. Unscrew pump far enough to expose rod retaining pin. Push retaining wire clip up. Push pin out. Continue unscrewing pump.




Pump A
Figure 3

- 1 Flat side faces up.
- 2 Lubricate threads with ISO oil or grease.
- 3 Pump top threads must be nearly flush with bearing face (N).

Note

Steps 12 and 13 apply to pump B.

12. Disconnect fluid inlet (C) and outlet (D). Also disconnect steel outlet tube from heater inlet.
13. Push retaining wire clip (E) up. Push pin (F) out. Loosen locknut (G) by hitting firmly with a non-sparking hammer. Unscrew pump.



Pump B
Figure 4

- 1 Flat side faces up.
- 2 Lubricate threads with ISO oil or grease.
- 3 Pump top threads must be nearly flush with bearing face (N).

Install Pump

Note

Steps 1–5 apply to pump B. To reconnect pump A, proceed to step 6.

1. Ensure locknut (G) is screwed on pump with flat side up. Screw pump into bearing housing (M) until pin holes align. Push pin (F) in. Pull retaining wire clip (E) down. See Fig. 4 for view and assembly notes.
2. Continue screwing pump into housing until fluid outlet (D) is aligned with steel tube and top threads are +/- 1/16 in. (2 mm) of bearing face (N).
3. Tighten locknut (G) by hitting firmly with a non-sparking hammer.
4. Reconnect fluid inlet (C) and outlet (D).
5. Go to step 13.

Note

Steps 6–12 apply to pump A only.

6. Ensure star-shaped locknut (G) is screwed on pump with flat side up. Carefully twist and extend displacement rod 2 in. (51 mm) above wet-cup.




Figure 5

7. Start threading pump into bearing housing (M). When pin holes align, insert pin. Pull retaining wire clip down.
8. Continue threading pump into bearing housing (M) until top threads are +/- 1/16 in. (2 mm) of bearing face (N). Ensure that barbed fittings at wet-cup flush ports are accessible.
9. Connect component A outlet tube loosely at pump and at heater. Line up tube, then tighten fittings securely.
10. Tighten star-shaped locknut (G) by hitting firmly with a non-sparking hammer.

11. Apply thin film of TSL to barbed fittings. Using two hands, support tubes (T) while pushing straight onto barbed fittings. Secure each tube with a wire tie between two bars.




Note


Do not let tubes kink or buckle.

12. Reconnect fluid inlet (C).
13. Purge air and prime the system. See Reactor operation manual.


Repair Drive Housing

Removal

1. Press  to stop the pumps.
2. Turn off heat zones.
3. Flush pump.
4. Press  to park the pumps in the down position.
5. Press  to deactivate the system.
6. Turn main power switch off.



7. Perform [Pressure Relief Procedure](#), page 46.
8. Remove the system frame from the floor and L-brackets.



9. Remove two bolts and nuts and fold the electrical enclosure backward.
10. Remove screws (21) and motor shroud (11). Rest the motor shroud behind the motor without straining the fan power cable.

Note

Examine bearing housing (103) and connecting rod (105). If these parts need replacing, first remove the pump (106), see [Remove Pump](#), page 52.

11. Remove cover (60) and screws (21).
12. Remove cycle counter (121) from housing by removing screw (122).
13. Disconnect pump inlet and outlet lines. Remove screws (113), washers (115), and bearing housing (103).

NOTICE

Do not drop gear cluster (104) when removing drive housing (102). Gear cluster may stay engaged in motor front end bell or drive housing.

14. Remove screws (112, 119) and washers (114) and pull drive housing (102) off motor (101).

Note

The A side drive housing includes cycle counter switch (121). If replacing this housing, remove screws (122) and switch. Reinstall screws and switch on new drive housing.




Figure 6

Installation

1. Apply heavy duty extreme pressure grease liberally to washers (107, 108, 118), all gears, and inside drive housing (102).
2. Install one bronze washer (108) in drive housing, then install steel washers (107, 118) as shown.
3. Install second bronze washer (108) on gear cluster (104) and insert gear cluster in drive housing.

Note

Drive housing crankshaft must be in line with crankshaft at other end of motor.

4. Push drive housing (102) onto motor (101). Install screws (112) and washers (114).

Note

If bearing housing (103), connecting rod (105), or pump (106) were removed, reassemble rod in housing and install pump, see [Install Pump, page 53](#).

5. Route cycle counter switch cable (121) around the motor fan and reattach to housing (102) with screws (122).
6. Install bearing housing (103), screws (113), and washers (114). Pumps must be in phase (both at same position in stroke).
7. Install cover (60) and screws (21).
8. Install motor shield (11) and screws (21).




Figure 7


Repair Electric Motor

Removal


NOTICE

Be careful not to drop or damage the motor. The motor is heavy and may require two people to lift.

1. Remove the system frame from the floor and L-brackets.




2. Remove drive housing and pump assemblies. See [Repair Drive Housing, page 54](#).
3. Disconnect electric motor (101) power cable from port #15 on the MCM. Remove connector by loosening four terminal screws.
4. Remove motor shroud (11). Rest the motor shroud assembly behind the motor without straining the fan power cable.
5. Disconnect over temperature cable from port #2 on MCM. Cut tie wraps around harness to remove cable.
6. Remove four screws (25) holding motor (101) to bracket. Lift motor off unit.



Installation

1. Place motor on unit. Thread motor cables into conduit as before. See [Electrical Schematics, page 93](#).
2. Fasten motor with screws (25) until screws are fully threaded in frame. Do not tighten screws until drive housing and pumps are connected to the motor.
3. Install drive housing and pump assemblies, see [Installation, page 56](#).
4. Route motor (101) power cord from motor through conduit and connect to port #15 on MCM. Route over temperature cable up from motor and connect to port #2 on MCM. Insert cables in conduit and use tie wraps to secure the conduit together.
5. Connect motor shroud assembly to motor (101).
6. Install drive housing covers and motor cover.
7. Return to service.

Repair Circuit Breaker Module



1. See [Before Beginning Repair, page 50](#).
2. Using an ohmmeter, check for continuity across circuit breaker (top to bottom). If no continuity, trip breaker, reset, and retest. If still no continuity, replace breaker as follows:
 - a. Refer to [Electrical Schematics, page 93](#), and circuit breaker table.
 - b. Follow Shutdown instructions. See [Shutdown, page 47](#).
 - c. Refer to circuit breaker identification table and electrical diagrams in Reactor repair manual.
 - d. Loosen two screws connecting wires and bus bar to circuit breaker that will be replaced. Disconnect wires.
 - e. Pull locking tab out 1/4 in. (6mm) and pull circuit breaker away from the din rail. Install

new circuit breaker. Insert wires and tighten down all screws.




Figure 8
Circuit Breakers

| Circuit Breakers | | |
|------------------|------|----------------------------|
| Ref. | Size | Component |
| CB01 | 50 A | Heated Hose |
| CB02 | 20 A | Motor Control Module (MCM) |
| CB03 | 40 A | ISO Heater |
| CB04 | 40 A | RES Heater |
| CB05 | 40 A | Hose Heat Transformer |

Replace Fluid Inlet Sensor

Note

For Elite models only.

1. Perform [Shutdown](#), page 47.
2. Perform [Pressure Relief Procedure](#), page 46.
3. Disconnect inlet sensor cable from the fluid inlet assembly. Inspect cable for damage and replace if necessary. See [Electrical Schematics](#), page 93.




Figure 9 Fluid Inlet Sensor

4. To replace sensor cable:
 - a. Open wire bundle and remove sensor cable.
 - b. Cut any wire ties and disconnect from MCM. See [Electrical Schematics](#), page 93.


NOTICE

To prevent damage to cable, route and secure cable in wire bundle with wire ties.


5. Replace sensor (602).

Replace Pressure Transducers

1. Perform [Shutdown](#), page 47.
2. Perform [Pressure Relief Procedure](#), page 46.
3. Disconnect transducer cables (405) from #6 and #7 connectors on the MCM.
4. Remove wire ties constraining transducer cable and remove cable from cabinet.
5. Install o-ring (416) on new transducer (405).
6. Install transducer in manifold. Mark end of cable with tape (red=transducer A, blue=transducer B).
7. Route new cable into cabinet and thread into bundle as before. Attach cable ties to bundle as before.
8. Connect A side pressure transducer cable to MCM port #6. Connect B side pressure transducer cable to MCM port #7.



Replace Fans



Replace Motor Fan

1. Perform [Shutdown](#), page 47.
2. Open cabinet door and disconnect fan cables from terminal blocks. See [Electrical Schematics](#), page 93.
3. Remove four screws (21) from motor cover (11). If necessary, fold frame (1) to remove motor cover (10). See [Repair Drive Housing](#), page 54, steps 1–10.
4. Cut tie wraps to remove cable.
5. Remove nuts (39), screws (22), washers (34) and fan (32). Install new fan in reverse order.

Note

Ensure fan (32) blows onto motor.




Figure 10

Replace Electrical Enclosure Fan

1. Perform [Shutdown](#), page 47
2. Open electrical enclosure door (401). Loosen four nuts (421) and remove fan (404).
3. Install new fan (404) in reverse order of disassembly so that the fan blows out of the electrical enclosure.





Figure 11

Replace Transformer Fan



1. Perform [Shutdown](#), page 47.
2. Remove four bolts (23) and shroud (10).
3. Remove bolt (20) on top of the heater junction box (48).
4. Disconnect fan and transformer connections from terminal blocks. Connections are on left side labeled: V+, V-, 1, 2, 3, and 4.
5. Remove four nuts (27) holding metal transformer cover (8) to frame. Carefully remove cover while sliding wires through hole in cover.
6. Remove four screws (23), washers (29), and fan (32).
7. Install fan in reverse order.







Figure 12


Repair Primary Heater





Replace Heater Element




1. Press  to stop the pumps.
2. Turn off heat zones.



3. Flush pump.
4. Press  to park the pumps in the down position. The park operation is complete when green dot goes out. Verify the park operation is complete before moving to next step.




5. Press  to deactivate the system.




6. Turn main power switch off.



7. Relieve pressure. See [Pressure Relief Procedure, page 46](#).



8. Wait for heater to cool.
9. Remove four bolts (23) and shroud (10).



10. Remove screw (20) and lower din rail cover (48).
11. Disconnect heater wires:
 - a. A Side: Disconnect A side heater wires, transformer, and transformer fan wires from lower din rail (33).
 - b. B Side: Disconnect B side heater wires and remove lower din rail (33) from B side heater (5).
12. Test heater wires with ohmmeter.

| System | Total Heater Wattage | Element | Ohms |
|---------------------|----------------------|---------|-------------------|
| E-30 (10 kw) | 10,200 | 2,550 | 18–21 per element |
| E-XP2, E-30 (15 kw) | 15,300 | 2,550 | 18–21 per element |

NOTICE

To prevent a short circuit or lowering the transformer life, do not splash fluid on transformer. Cover transformer with a plastic sheet or piece of cardboard.

13. Remove nuts (27) and transformer cover (8). Cover transformer with plastic sheet or cardboard.
14. Disconnect overtemperature switches (209) from cable.
15. Loosen ferrule nut (N). Remove RTD (212) from heater housing. Do not remove adapter (206) unless necessary. If adapter must be removed, ensure that mixer (210) is out of the way when replacing adapter.
16. Disconnect inlet and outlet fluid tubes from heater.
17. Remove two bolts (23) and lift heater over transformer.
18. Place heater block (201) in a vise. Use a wrench to remove heater element (208).
19. Inspect element. It should be relatively smooth and shiny. Replace element if there is a crusted, burnt, ash-like material adhered to element, or sheath shows pitting marks.
20. Install new heater element (208), holding mixer (210) so it does not block RTD port.
21. Secure heater to frame with bolts (23).
22. Reinstall RTD (212), [Repair Primary Heater, page 62](#).
23. Reconnect cable to overtemperature switches (209).
24. Reconnect wires to lower din rail. If necessary, install lower din rail (33).
25. Install lower din rail cover (48).

Line Voltage

The heater outputs its rated wattage at 240 VAC. Low line voltage will reduce power available and the heater will not perform at full capacity.





Figure 13

Repair Overtemperature Switch

1. Perform [Shutdown](#), page 47.
2. Wait for heaters to cool.
3. Remove heater cover (10).
4. Disconnect overtemperature switches (209) from cable (46). Test across spade terminals with ohmmeter.
 - a. If the resistance **is not** approximately 0 ohms, the overtemperature switch needs to be replaced. Go to step 5.
 - b. If the resistance **is** approximately 0 ohms, inspect cable (46) to ensure it is not cut or open. Reconnect the overtemperature switch (209) and cable (46). Disconnect cable from TCM. Test from pin 1 to 3 and 1 to 4. If resistance is not approximately 0, and switches are 0. Replace cable in place of original cable.
5. If switch fails test, remove screws. Discard failed switch. Apply a thin layer of thermal compound

110009, install new switch in same location on housing (201), and secure with screws (213). Reconnect cables.



Replace RTD

1. Perform [Shutdown, page 47](#).
2. Wait for heater to cool.
3. Remove heater cover (10).
4. Cut cable ties around the woven wrap with the RTD cable (212).
5. Disconnect RTD cable(212) from TCM (453).
6. Loosen ferrule nut (N). Remove RTD (212) from heater housing (201), then remove RTD housing (H). Do not remove the adapter (206) unless necessary. If adapter must be removed, ensure that mixer (210) is out of the way when replacing the adapter.
7. Remove RTD cable (212) from woven wrap.
8. Replace RTD (212).
 - a. Apply PTFE tape and thread sealant to male pipe threads and tighten RTD housing (H) into adapter (206).
 - b. Push in RTD (212) so tip contacts heater element (208).
 - c. Holding RTD (212) against heater element, tighten ferrule nut (N) 3/4 turn past finger-tight.
9. Route wires (S) as before through woven wrap and reconnect RTD cable (212) to the TCM.
10. Replace heater shroud (10).
11. Follow startup instructions in the operation manual. Turn on A and B heat simultaneously to test. Temperatures should rise at same rate. If one is low, loosen ferrule nut (N) and tighten RTD housing (H) to ensure RTD tip contacts element (212) when ferrule nut (N) is retightened.




Figure 14

Repair Heated Hose

Refer to the heated hose manual 309572 for hose replacement parts.

Check Hose Heat Power Connectors

1. Perform [Shutdown](#), page 47.

Note

Whip hose must be connected.

2. Disconnect power harness (PM) from hose termination box terminal block (TB).




Figure 15

3. For Series A only: Disconnect hose connector (D) at Reactor.




Figure 16


4. Using an ohmmeter, check between the connectors (D). There should be continuity.
5. If hose fails test, retest at each length of hose, including whip hose, until failure is isolated.

Check RTD Cables and FTS

1. Perform [Shutdown](#), page 47.
2. Disconnect RTD cable (C) at Reactor.
3. Test with an ohmmeter between pins of cable connector C.


Note

Do not touch outer ring with test probe.



| Pins | Result |
|----------|-------------------------|
| 3 to 1 | approximately 1090 ohms |
| 3 to 4 | approximately 1090 ohms |
| 1 to 4 | 0.2 - 0.4 ohms |
| 2 to any | infinity (open) |

4. Retest at each length of hose, including whip hose, until failure is located.
5. If the FTS is not reading properly at the end of the hose, connect FTS directly to RTD cable (C) at the manifold.
6. If the FTS reads properly at the manifold but not at the end of the hose, check cable (C) connections. Verify they are tight.



Heated Hose
Figure 17

Note

To assist in taking readings, order RTD Test Kit 24N365. Kit includes two cables: one cable with a compatible female M8 connector and another cable with a male M8 connector. Both cables have stripped wire at the other end for easy test probe access.

| Pins / Wire Color | Result |
|-------------------------|-------------------------|
| 3 to 1 / brown to blue | approximately 1090 ohms |
| 3 to 4 / blue to black | approximately 1090 ohms |
| 1 to 4 / brown to black | 0.2 - 0.4 ohms |
| 2 to any / N/A | infinity (open) |

Repair Fluid Temperature Sensor (FTS)

Installation

The Fluid Temperature Sensor (FTS) is supplied with the system. Install FTS between main hose and whip hose. See Heated Hose manual 309572 for instructions.




Figure 18

Test/Removal

1. Perform [Shutdown, page 47](#).
2. Remove tape and protective covering from FTS. Disconnect hose cable (F).
3. If FTS is not reading properly at the end of the hose, see [Check RTD Cables and FTS, page 67](#).
4. If FTS fails, replace FTS.

- a. Disconnect air hoses (C,L) and electrical connectors (D).
- b. Disconnect FTS from whip hose (W) and fluid hoses (A, B).
- c. Remove ground wire (K) from ground screw on underside of FTS.
- d. Remove FTS probe (H) from component A (ISO) side of hose.

Transformer Primary Check

See [Electrical Schematics, page 93](#).

1. Check wires and transformer:
 - a. See [Shutdown, page 47](#).
 - b. Shut off CB05.
 - c. Use an ohmmeter to test for continuity between terminals 2 and 4 of CB05. If there is no continuity, check transformer.
2. Check transformer:
 - a. See [Shutdown, page 47](#).
 - b. Remove lower shroud.
 - c. Locate the two smaller (10 AWG) wires, labeled 1 and 2, coming out of transformer. Trace these wires back to terminal blocks TB15 and TB16.
 - d. Use an ohmmeter to test for continuity between two wires; there should be continuity.

Transformer Secondary Check

See [Electrical Schematics, page 93](#).

1. Check wires and transformer:
 - a. Disconnect 7 pin green connector from TCM.
 - b. Use an ohmmeter to test for continuity between terminals 6 and 7 on the TCM 7 pin green connector. There should be continuity. If there is no continuity, check transformer.
 - c. Reconnect 7 pin green connector to TCM
2. Check transformer:
 - a. Remove lower shroud.
 - b. Locate the two larger (6 AWG) wires, labeled 3 and 4, coming out of transformer. Trace these wires back to TB17 and TB18. Open circuit breaker CB01 to turn the color

indicator on the circuit breaker GREEN. Use an ohmmeter to test for continuity between two transformer wires in terminal blocks TB17 and TB18; there should be continuity.

- c. Close the circuit breaker CB01.





Figure 19

- d. Apply incoming power to system.
- e. To verify voltage on the secondary leads of the transformer, measure between the terminals terminals 3 and 4 on TB17 and TB18. Verify voltage is approximately 90 VAC for 240 VAC input.
- f. See the Diagnostic Run Screen on the ADM. The Diagnostic Run Screen displays the incoming (90 Vac) to the TCM "Hose Voltage". The diagnostic screen will show if the circuit breaker has been tripped for the incoming power to the TCM.

| 12/20/13 09:00 | | |
|------------------------------|------------|---------------|
| Job Data Diagnostic Home | | |
| E-30 Active No Active Errors | | |
| A Chemical | B Chemical | Hose Chemical |
| 70 °F | 70 °F | 70 °F |
| A Current | B Current | Hose Current |
| 0 A | 0 A | 0 A |
| TCM PCB | | |
| 70 °F | | |
| Pressure A | Pressure B | Hose Voltage |
| 0 psi | 0 psi | 90 V |
| MCM Bus | CFM | Total Cycles |
| 400 V | 0 | 0 |

Replace Transformer



1. Perform [Shutdown](#), page 47.
2. Remove four bolts (23) and shroud (10).
3. Remove lower dinrail cover (48).
4. Disconnect fan and transformer connections from terminal blocks. Connections are on left side labeled: V+, V-, 1, 2, 3, and 4.
5. Remove four nuts (27) holding metal transformer cover (8) to frame. Carefully remove cover while sliding wires through hole in cover.
6. Remove nuts (27) and transformer (17).
7. Install transformer (17) in reverse order.





Figure 20

Replace Power Supply



1. Perform [Shutdown](#), page 47.
2. Disconnect input and output cables from both sides of the power supply. See [Electrical Schematics](#), page 93.
3. Insert a flat head screw driver in the mounting tab on the bottom of the power supply to remove from the din rail.
4. Install new power supply (535) in reverse order.




Figure 21 24 VDC Power Supply

Replace Surge Protector

1. Loosen connections on terminals 1 and 3 on CB02.
2. Loosen connections on input to power supply (535) on N and L connections.
3. Remove two screws (413) and surge protector (505) from enclosure.
4. Install new surge protector (505) in reverse order.

Note

Wire on both the circuit breaker and power supply are interchangeable.




Figure 22 Surge Protector

Replace Advanced Display Module (ADM)

1. Loosen four screws (70) on inside of electrical enclosure door (61). Lift up and pull out to remove ADM (88).
2. Disconnect CAN cable (475).
3. Inspect ADM (88) for damage. Replace if necessary.




Figure 23

Replace Motor Control Module (MCM)

1. Perform [Shutdown, page 47](#).
2. Disconnect connectors from MCM (63). Disconnect two power cables. See [Electrical Schematics, page 93](#).
3. Remove nuts (91) and MCM (63).
4. Set rotary switch. 2= E-30 and 3= E-XP2.
5. Replace MCM in enclosure.
6. Connect cables to MCM. See [Electrical Schematics, page 93](#).




Figure 24 Replace MCM

Replace Temperature Control Module (TCM)

1. Perform [Shutdown, page 47](#).
2. Open electrical enclosure door (61).
3. Disconnect all connectors from the TCM (453).
4. Remove four nuts (461) and TCM (453).
5. Install new TCM module (453). Reassemble parts in reverse order.




Figure 25 Replace TCM


Software Update Procedure

NOTICE


Repair kit GCA modules are shipped pre-programmed and software loading is not necessary. If software version upgrade is necessary, follow the procedure in the manual provided.

Parts

Proportioners



Parts



- △1 Apply anaerobic polyacrylate pipe sealant to all non-swiveling pipe threads.
- △2 Apply grease to tube fitting threads. Torque to 43 ft-lbs (58 N•m).
- △3 Safety and warning labels are from label sheet (68).

| Ref | Part | Description | Quantity | | | | | |
|-----|--------|---|----------|--------|--------|--------|--------|--------|
| | | | 272010 | 272011 | 272012 | 272110 | 272111 | 272112 |
| 1 | - - - | FRAME | 1 | 1 | 1 | 1 | 1 | 1 |
| 2 | - - - | ENCLOSURE, electrical; see Electrical Enclosure, page 86 | 1 | 1 | 1 | 1 | 1 | 1 |
| 3 | 246995 | BOTTLE, assembly, complete | 1 | 1 | 1 | 1 | 1 | 1 |
| 4 | 16X531 | BRACKET, tsl, bottle | 1 | 1 | 1 | 1 | 1 | 1 |
| 5 | 24U843 | HEATER, 10kw, 2 zone, RTD; see Fluid Heater, page 82 | 1 | | | 1 | | |
| | 24U842 | HEATER, 7.5kw, 1 zone, RTD; see Fluid Heater, page 82 | | 2 | 2 | | 2 | 2 |
| 6 | 24U704 | MANIFOLD, fluid; see Fluid Manifold, page 84 | 1 | 1 | 1 | 1 | 1 | 1 |
| 7 | 16W654 | INSULATOR, foam, heater | 2 | 4 | 4 | 2 | 4 | 4 |
| 8 | 24R684 | COVER, transformer | 1 | 1 | 1 | 1 | 1 | 1 |
| 9+ | 261821 | CONNECTOR, wire, 6awg | 1 | 1 | 1 | 1 | 1 | 1 |
| 10 | 24U841 | COVER, heater | 1 | 1 | 1 | 1 | 1 | 1 |
| 11 | 16W765 | COVER, motor | 1 | 1 | 1 | 1 | 1 | 1 |
| 12 | 16W764 | COVER, heater, rear | 1 | 1 | 1 | 1 | 1 | 1 |
| 13 | 24U837 | TUBE, b-side, inlet, 15 kW | | 1 | 1 | | 1 | 1 |
| | 24U838 | TUBE, b-side, inlet, 10kw | 1 | | | 1 | | |
| 14 | 24U839 | TUBE, b-side, outlet, 15 kW | | 1 | 1 | | 1 | 1 |
| | 24U840 | TUBE, b-side, outlet, 10kw | 1 | | | 1 | | |
| 15 | 24U834 | TUBE, a-side, inlet, 10 kW | 1 | | | 1 | | |
| | 24U833 | TUBE, a-side, inlet, 15 kW | | 1 | 1 | | 1 | 1 |
| 16 | 24U836 | TUBE, a-side, outlet, 10 kW | 1 | | | 1 | | |
| | 24U835 | TUBE, a-side, outlet, 15 kW | | 1 | 1 | | 1 | 1 |
| 17 | 15K742 | TRANSFORMER, 4090va, 230/90 | 1 | 1 | 1 | 1 | 1 | 1 |
| 18 | 15B456 | GASKET, manifold | 1 | 1 | 1 | 1 | 1 | 1 |

Parts

| Ref | Part | Description | Quantity | | | | | |
|-----|--------|--|----------|--------|--------|--------|--------|--------|
| | | | 272010 | 272011 | 272012 | 272110 | 272111 | 272112 |
| 19 | 125643 | FITTING, elbow, 3/8 npt x #8 jic | 2 | 2 | 2 | 2 | 2 | 2 |
| 20 | 119865 | SCREW, mch, hex serrated; 3/8 in. x 1/4-20 | 9 | 9 | 9 | 9 | 9 | 9 |
| 21 | 118444 | SCREW, mch, slot hex wash hd; 1/2 in. x #10-24 | 12 | 12 | 12 | 12 | 12 | 12 |
| 22 | 117683 | SCREW, mch, phil pan hd; 1.5 in. x #6-32 | 8 | 8 | 8 | 8 | 8 | 8 |
| 23 | 113796 | SCREW, flanged, hex hd; 3/4 in. x 1/4-20 | 11 | 13 | 13 | 11 | 13 | 13 |
| 24 | 112731 | NUT, hex, flanged | 6 | 6 | 6 | 6 | 6 | 6 |
| 25 | 111800 | SCREW, cap, hex hd; 7/32 in. x 5/16-18 | 4 | 4 | 4 | 4 | 4 | 4 |
| 26 | 111218 | CAP, tube, square | 2 | 2 | 2 | 2 | 2 | 2 |
| 27 | 110996 | NUT, hex, flange head | 8 | 8 | 8 | 8 | 8 | 8 |
| 28 | 104859 | SCREW, tapping pnhd; 5/16 in. x #10-16 | 2 | 2 | 2 | 2 | 2 | 2 |
| 29 | 103181 | WASHER, lock ext | 4 | 4 | 4 | 4 | 4 | 4 |
| 30 | 100020 | WASHER, lock | 2 | 2 | 2 | 2 | 2 | 2 |
| 31 | 115836 | GUARD, finger | 1 | 1 | 1 | 1 | 1 | 1 |
| 32 | 24U847 | FAN, cooling, 120mm, 24vdc | 2 | 2 | 2 | 2 | 2 | 2 |
| 33 | 24R685 | ENCLOSURE, lower, dinrail; includes 33a-33d | 1 | 1 | 1 | 1 | 1 | 1 |
| 33a | 24U849 | KIT, module, din rail, heater; see Heater and Transformer Terminal Block Module, page 89 | 1 | 1 | 1 | 1 | 1 | 1 |
| 33b | 16W667 | INSULATOR, FOAM | 1 | 1 | 1 | 1 | 1 | 1 |
| 33c | - - - | COVER, bottom, dinrail | 1 | 1 | 1 | 1 | 1 | 1 |
| 33d | 113505 | NUT, keps, hex hd | 1 | 1 | 1 | 1 | 1 | 1 |
| 34 | 151395 | WASHER, flat | 4 | 4 | 4 | 4 | 4 | 4 |
| 35 | 120685 | GROMMET | 2 | 2 | 2 | 2 | 2 | 2 |
| 36 | 114269 | GROMMET, rubber | 1 | 1 | 1 | 1 | 1 | 1 |
| 37 | 125625 | TIE, cable, fir tree | 5 | 6 | 6 | 5 | 6 | 6 |
| 38 | 127277 | BOLT, carriage, 1/2-13 x 3.5 l | 4 | 4 | 4 | 4 | 4 | 4 |
| 39 | 127278 | NUT, keps, hex | 4 | 4 | 4 | 4 | 4 | 4 |
| 40 | 127282 | GROMMET, rubber | 4 | 4 | 4 | 4 | 4 | 4 |

| Ref | Part | Description | Quantity | | | | | |
|------|--------|--|----------|--------|--------|--------|--------|--------|
| | | | 272010 | 272011 | 272012 | 272110 | 272111 | 272112 |
| 41 | 16X095 | CONNECTOR, power, male, 4 pin | 1 | 1 | 1 | 1 | 1 | 1 |
| 42 | 125871 | TIE, cable, 7.5 in. | 25 | 25 | 25 | 25 | 25 | 25 |
| 43 | 24K207 | KIT, fts, rtd, single hose | 1 | 1 | 1 | 1 | 1 | 1 |
| 44 | 24R725 | BRIDGE, plug-in jumper, ut35 | 4 | 4 | 4 | 4 | 4 | 4 |
| 45 | 106569 | TAPE, electrical | 1 | 1 | 1 | 1 | 1 | 1 |
| 46● | 24T242 | CABLE, over-temp, 10 kW Reactor | 1 | | | 1 | | |
| | 24P970 | CABLE, over-temp, 15 kW Reactor | | 1 | 1 | | 1 | 1 |
| 47 | 104765 | PLUG, pipe headless | 2 | 2 | 2 | 2 | 2 | 1 |
| 48 | 16V268 | COVER, top, dinrail | 1 | 1 | 1 | 1 | 1 | 1 |
| 49 | 15Y118 | LABEL, made in the USA | 1 | 1 | 1 | 1 | 1 | 1 |
| 50 | 24V150 | PROPORTIONER, module, E-30; see Proportioner Module, page 80 | 1 | 1 | | 1 | 1 | |
| | 24V151 | PROPORTIONER, module, E-XP2; see Proportioner Module, page 80 | | | 1 | | | 1 |
| 51 | 24U321 | KIT, asm, pair, elite, reactor; see Fluid Inlet Kits, page 91 | | | | 1 | 1 | 1 |
| | 24U320 | KIT, assembly, pair, std, reactor; see Fluid Inlet Kits, page 91 | 1 | 1 | 1 | | | |
| 52●◆ | 16X118 | MODULE, cellular, gps, temp | | | | 1 | 1 | 1 |
| 53●◆ | 24T050 | CABLE, m8 4p f to m12 8p m 1.5m | | | | 1 | 1 | 1 |
| 54● | 16W130 | CABLE, m12 5p, fem - male, 2.0m | | | | 2 | 2 | 2 |
| 55 | 24U845 | TUBE, pressure relief | 2 | 2 | 2 | 2 | 2 | 2 |
| 56 | 191892 | FITTING, elbow, street, 90 deg; 1/8 npt | 2 | 2 | 2 | 2 | 2 | 2 |
| 57 | 116746 | FITTING, barbed, plated; 1/8-27 npt x 1/4 in. hose I.D. | 2 | 2 | 2 | 2 | 2 | 2 |

Parts

| Ref | Part | Description | Quantity | | | | | |
|-----|--------|--|----------|--------|--------|--------|--------|--------|
| | | | 272010 | 272011 | 272012 | 272110 | 272111 | 272112 |
| 58 | 16W218 | LABEL, branding, e-30 | 1 | 1 | | | | |
| | 16W321 | LABEL, branding, e-30, elite | | | | 1 | 1 | |
| | 16W215 | LABEL, branding, e-xp2 | | | 1 | | | |
| | 16W322 | LABEL, branding, e-xp2, elite | | | | | | 1 |
| 59 | 16U530 | MODULE, system surge protector (spare) | 1 | 1 | 1 | 1 | 1 | 1 |
| 60 | 15G349 | COVER, drive, plastic | 2 | 2 | 2 | 2 | 2 | 2 |
| 61 | 16W766 | COVER, control, box | 1 | 1 | 1 | 1 | 1 | 1 |
| 62 | 16W596 | LATCH, door | 2 | 2 | 2 | 2 | 2 | 2 |
| 63 | 24U832 | MODULE, MCM | | | | 1 | 1 | 1 |
| | 24U831 | MODULE, MCM | 1 | 1 | 1 | | | |
| 64 | 206995 | FLUID, tsl, 1 qt. | 1 | 1 | 1 | 1 | 1 | 1 |
| 65 | 206994 | FLUID, tsl 8 oz bottle | 1 | 1 | 1 | 1 | 1 | 1 |
| 67 | 114225 | TRIM, edge protection; 1.6 ft (0.48 m) | 1 | 1 | 1 | 1 | 1 | 1 |
| 68 | 16X250 | LABEL, identification | 1 | 1 | 1 | 1 | 1 | 1 |
| 70 | 127296 | SCREW, mchn, pnh, w/ext tooth wash; M4 x 0.7 | 4 | 4 | 4 | 4 | 4 | 4 |
| 71 | 16X129 | SCREW, mach, phillips, tooth wash; 5/16 x 8-32 | 10 | 10 | 10 | 10 | 10 | 10 |
| 72 | 117502 | FITTING, reducer #5 x #8 (JIC) | 1 | 1 | 1 | 1 | 1 | 1 |
| 73 | 117677 | FITTING, reducer #6 x #10 (JIC) | 1 | 1 | 1 | 1 | 1 | 1 |
| 74 | 299521 | CAP, 1/2-20 jic cap-aluminum | 1 | 1 | 1 | 1 | 1 | 1 |
| 75 | 299520 | CAP, 9/16-18 JIC cap-aluminum | 1 | 1 | 1 | 1 | 1 | 1 |
| 79+ | 261843 | FLUID, oxide inhibitor | 1 | 1 | 1 | 1 | 1 | 1 |
| 81 | 16V806 | BRACKET, wall, mount | 2 | 2 | 2 | 2 | 2 | 2 |
| 82 | 15V551 | SHIELD, membrane, ADM (10 pack) | 1 | 1 | 1 | 1 | 1 | 1 |
| 83 | 24K409 | BAR, 55 gal chem. measure; A side | 1 | 1 | 1 | 1 | 1 | 1 |
| 84 | 24K411 | BAR, 55 gal chem. measure. B side | 1 | 1 | 1 | 1 | 1 | 1 |

| Ref | Part | Description | Quantity | | | | | |
|------|--------|-------------------------------------|----------|--------|--------|--------|--------|--------|
| | | | 272010 | 272011 | 272012 | 272110 | 272111 | 272112 |
| 85 | 127276 | BOLT, carriage, 1/2-13 x 2.5 l | 2 | 2 | 2 | 2 | 2 | 2 |
| 88 | 24U854 | MODULE, ADM | 1 | 1 | 1 | 1 | 1 | 1 |
| 89 | 16W967 | FITTING, swivel, 3/4 npt x 1 npsm | 2 | 2 | | 2 | 2 | |
| | 118459 | FITTING, union, swivel, 3/4 in. | | | 2 | | | 2 |
| 90 | 16W213 | LABEL, branding, reactor | 2 | 2 | 2 | 2 | 2 | 2 |
| 91 | 115942 | NUT, hex, flange head | 4 | 4 | 4 | 4 | 4 | 4 |
| 92● | 15D906 | SUPPRESSOR, round snap ferrite .260 | 1 | 1 | 1 | 1 | 1 | 1 |
| 93 | 127368 | SLEEVE, split, wire, 1.50 ID | 2 | 2 | 2 | 2 | 2 | 2 |
| 94 | 127377 | TIE, cable, 6 in. | | | | 1 | 1 | 1 |
| 95 | 16X154 | LABEL, InSite | | | | 1 | 1 | 1 |
| 96 | 333091 | MANUAL, quick guide, startup | 1 | 1 | 1 | 1 | 1 | 1 |
| 97 | 333092 | MANUAL, quick guide, shutdown | 1 | 1 | 1 | 1 | 1 | 1 |
| 98* | 24W204 | ENCLOSURE, terminal block | 1 | 1 | 1 | 1 | 1 | 1 |
| 99* | 25A234 | ENCLOSURE, cover | 1 | 1 | 1 | 1 | 1 | 1 |
| 100* | 189930 | LABEL, caution | 1 | 1 | 1 | 1 | 1 | 1 |
| 101* | 172953 | LABEL, ground | 1 | 1 | 1 | 1 | 1 | 1 |
| 102* | 17D955 | BRACKET, mounting | 1 | 1 | 1 | 1 | 1 | 1 |
| 103* | 113161 | SCREW, flange, hex hd | 2 | 2 | 2 | 2 | 2 | 2 |

Replacement Warning labels, signs, tags, and cards are available at no cost.

Not shown.


◆ Parts included in Graco Insite Kit 24T280.

● See [Electrical Schematics, page 93](#).

+ Part applies to Series A only.

* Part applies to Series B only.

Proportioner Module
24V150, Module for E-30
24V151, Module for E-XP2



- △1 Torque to 190–120 in-lbs (21–24 N•m).
- △2 Lubricate threads with ISO oil or grease. Assemble pump cylinders flush to one full thread under-flush of housing surface.
- △3 Apply grease to all gear teeth proportionally, motor pinion and drive housing.
- △4 Torque to 20–30 ft-lbs (27–40.6 N•m).
- △5 Crankshaft must be in line with crankshaft at other end of motor.
- △6 Torque to 70–80 ft-lbs (95–108 N•m).
- △7 Flat side faces up.

| Ref | Part | Description | 24V150 E-30 | 24V151 E-XP2 |
|------|--------|---|----------------|-----------------|
| 101 | 24U050 | MOTOR, brushless, double ended, 2 HP | 1 | 1 |
| 102❖ | - - - | HOUSING, drive, Mark VII | 2 | 2 |
| 103 | 257355 | HOUSING, bearing | | 2 |
| | 245927 | HOUSING, bearing | 2 | |
| 104■ | 287290 | KIT, repair, gear | 2 | 2 |
| 105● | 241279 | KIT, rod, connecting | 2 | 2 |
| 106 | 245971 | PUMP, displacement B | | 1 |
| | 245972 | PUMP, displacement B | 1 | |
| 107■ | 114699 | WASHER, thrust; copper colored | 2 | 2 |
| 108■ | 114672 | WASHER, thrust; steel colored | 4 | 4 |
| 110● | 183169 | SPRING, retaining | 2 | 2 |
| 111 | 183210 | PIN, str, hdls | 2 | 2 |
| 112❖ | 15C753 | SCREW, machine, hex wash hd; 1.25 in. x 5/16-18 | 10 | 10 |
| 113 | 114666 | SCREW, cap, socket head; 2.25 x 3/8-16 | 8 | 8 |
| 114 | 106115 | WASHER, lock (hi-collar) | 8 | 8 |
| 115 | 246831 | PUMP, displacement, A | | 1 |
| | 246832 | PUMP, displacement, A | 1 | |
| 116 | 193031 | NUT, retaining | | 2 |
| | 193394 | NUT, retaining | 2 | |
| 118❖ | 116192 | WASHER, thrust (1595) | 2 | 2 |
| 120 | 116618 | MAGNET | 1 | 1 |
| 121 | 24P728 | SWITCH, reed, M8 4-pin | 1 | 1 |
| 122 | 127301 | SCREW, hexhead, thread cut, 4-40 x 0.375 | 2 | 2 |
| 125 | 187437 | LABEL, torque | 2 | 2 |
| 126 | 192840 | LABEL, warning | 2 | 2 |

Replacement Warning labels, signs, tags, and cards are available at no cost.

See pump repair manual 309577 for repair kits.

- Spring (110) included in Connecting Rod Kit 241279.


■ Gear Repair Kit includes washers (107) and (108).

❖ Drive Housing Repair Kit includes housing (1), screws (5), and washer (1) to replace one end.

Fluid Heater

24U843 — 10kW, 2-zone

24U842 — 7.5 kW, 1-zone




- △1 Torque to 120 ft-lbs (163 N•m).
- △2 Torque to 23 ft-lbs (31 N•m).
- △3 Torque to 40 ft-lbs (54 N•m).
- △4 Apply thermal paste.
- △5 Apply pipe sealant and PTFE tape to all non-swiveling threads and threads without o-rings.
- △6 Apply lithium grease lubricant to o-rings before assembling in block (1).
- △7 Remove tape from probe tip and Orientate sensor as shown. Insert probe until it bottoms on heating element. Tighten ferrule on sensor probe one turn past finger tight or 16 ft-lbs (21.6 N•m).




| Ref | Part | Description | 24U843 | 24U842 |
|------|--------|--|--------|--------|
| 201 | 15J090 | HEATER, machined, 1 zone | | 1 |
| | 15K825 | HEATER, machined, dual zone | 1 | |
| 202 | 124132 | O-RING | 4 | 3 |
| 203 | 15H305 | FITTING, plug, hollow, hex, 1-3/16 sae | 4 | 5 |
| 204 | 121309 | FITTING, adapter, sae-orb x jic | 4 | 2 |
| 205 | 15H304 | FITTING, plug 9/16 sae | 2 | 3 |
| 206 | 15H306 | ADAPTER, 9/16 x 1/8 | 2 | 1 |
| 207 | 120336 | O-RING, packing | 2 | 1 |
| 208 | 16A110 | HEATER, immersion, 2550W, 230V | 4 | 3 |
| 209 | 15B137 | SWITCH, over temperature | 1 | 1 |
| 210 | 15B135 | MIXER, immersion heater | 4 | 3 |
| 211* | - - - | FITTING, compression | 2 | 1 |
| 212* | - - - | SENSOR, RTD | 2 | 1 |
| 213 | 124131 | SCREW, machine, pnhd; 5/16 in. x #6-32 | 2 | 2 |
| 214 | 247520 | HOUSING, rupture disc | 2 | 1 |



* Included in 24L973 Heater RTD Repair Kit.

Fluid Manifold 24U844



ti22968a


-  Torque to 355–395 in.-lbs (40–44.6 N•m)
-  Apply sealant (113500) to threads.
-  Valve must be closed with handle position as shown on drawing.

-  Apply PTFE tape and thread sealant to gauge threads.
-  Apply grease on valve.
- **** Apply PTFE tape or thread sealant to tapered threads.

24U844, Fluid Manifold

| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|------|--------|--------------------------------------|-----|--|--------|------------------------------|-----|
| 401 | 255228 | MANIFOLD, fluid | 1 | 413 | 100840 | FITTING, elbow, street | 2 |
| 402 | 247824 | KIT, valve, cartridge, drain | 2 | 414 | 111457 | O-RING, PTFE | 2 |
| 402a | 158674 | O-RING, BUNA-N | 1 | 415 | 189285 | LABEL, caution | 1 |
| 402b | 247779 | SEAL, seat, valve | 1 | 416 | 150829 | SPRING, compression | 2 |
| 403 | 102814 | GAUGE, press, fluid | 2 | 419 | 117557 | NIPPLE, #10 JIC x 1/2 NPT | 1 |
| 404 | 162453 | FITTING, 1/4 NPSM X 1/4 NPT | 2 | <i>Replacement Warning labels, signs, tags, and cards are available at no cost.</i> <i>Included in the following complete valve kits: ISO Valve Kit (left/red) handle 255149. Resin Valve Kit (right/blue handle) 255150. Valve Set Kit (both handles and grease gun) 255148.</i> | | | |
| 405 | 15M669 | SENSOR, pressure, fluid outlet | 2 | | | | |
| 406 | 247788 | HANDLE, red | 1 | | | | |
| 407 | 247789 | HANDLE, blue | 1 | | | | |
| 408 | 112309 | NUT, hex, jam | 2 | | | | |
| 411 | 117556 | NIPPLE, #8 JIC x 1/2 NPT | 1 | | | | |
| 412 | 121312 | FITTING, elbow, 3/4 SAE x 1/2 JIC | 1 | | | | |

Electrical Enclosure



Electrical Enclosure


| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|-----|--------|---|-----|-----|--------|---|-----|
| 451 | 24U087 | ENCLOSURE | 1 | 468 | 111218 | CAP, tube, square | 2 |
| 453 | 24U855 | MODULE, TCM | 1 | 469 | 114269 | GROMMET, rubber | 1 |
| 454 | 24U848 | FAN, cooling, 80 mm, 24VDC | 1 | 470 | 127282 | GROMMET, rubber | 2 |
| 455 | 24R736 | SWITCH, disconnect, door mounted | 1 | 471 | 127278 | NUT, keps, hex | 4 |
| 457 | 117666 | TERMINAL, ground | 1 | 472 | 16W925 | GASKET, enclosure, foam | 2 |
| 458 | 120859 | NUT, strain relief, M40 thread | 1 | 473 | 16W926 | GASKET, enclosure, foam | 2 |
| 459 | 120858 | BUSHING, strain relief, M40 thread | 1 | 474 | 24R735 | CABLE, CAN power, M12 female, pigtail | 1 |
| 460 | 123967 | KNOB, operator disconnect | 1 | 475 | 127068 | CABLE, CAN, female/female 1.0 meter | 2 |
| 461 | 115942 | NUT, hex, flange head | 5 | 476 | 24U850 | MODULE, breaker | 1 |
| 462 | 103181 | WASHER, lock external | 2 | 477 | 127290 | CABLE, 4-pin, male/female, 1.3 meter, molded (hose RTD) | 1 |
| 463 | 124131 | SCREW, machine, pan head; 5/16 in. x #6-32 | 2 | 478 | 16X050 | LABEL, safety; enclosure | 1 |
| 464 | 194337 | WIRE, grounding, door | 1 | 479 | 16X049 | LABEL, safety; multi | 1 |
| 466 | 113505 | NUT, keps, hex head | 6 | | | | |

Replacement Warning labels, signs, tags, and cards are available at no cost.

See [Electrical Schematics](#), page 93.

System DIN Rail and Harness Module Kit 24U850, System DIN Rail and Harness Module Kit


See [Electrical Schematics, page 93](#).



- 1 Torque to 6–8 in.-lbs (0.7–1 N•m)
- 2 Torque to 28–33 in.-lbs (3–3.8 N•m)
- 3 Torque to 23–26 in.-lbs (2.6–3 N•m)


| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|-----|--------|---|-----|-----|--------|---|-----|
| 501 | 16U529 | HARNESS, breaker module | 1 | 504 | 16U526 | MODULE, din rail, circuit breakers; see Power Supply and Terminal Block Module, page 90 | 1 |
| 502 | 16V515 | HARNESS, hose out | 1 | | | | |
| 503 | 16U522 | MODULE, din rail, term blk, power sup; see System Circuit Breaker Module, page 90 | 1 | 505 | 16U530 | MODULE, sys surge protector | 1 |

Heater and Transformer Terminal Block Module 24U849




| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|-----|--------|-----------------------------------|-----|-----|--------|--------------------------------|-----|
| 511 | 24T315 | RAIL, DIN; 35 mm x 7.5 mm x 7 in. | 1 | 515 | 120570 | BLOCK, terminal | 6 |
| 512 | 126811 | BLOCK, clamp, end | 2 | 516 | 24R758 | BLOCK, terminal, UT-2.5, red | 1 |
| 513 | 126383 | COVER, end | 1 | 517 | 24R759 | BLOCK, terminal, UT-2.5, black | 1 |
| 514 | 126382 | BLOCK, terminal | 2 | | | | |

System Circuit Breaker Module 16U526



| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|-----|--------|--|-----|-----|--------|----------------------------------|-----|
| 521 | 514014 | RAIL, DIN; 35 mm x 7.5 mm x 8.625 in. | 1 | 524 | 17A314 | CIRCUIT, breaker, 2P, 20A, UL489 | 1 |
| 522 | 120838 | TERMINAL, end stop | 2 | 525 | 17A317 | CIRCUIT, breaker, 2P, 40A, UL489 | 3 |
| 523 | 17A319 | CIRCUIT, breaker, 1 pole, 50A, C Curve | 1 | | | | |

Power Supply and Terminal Block Module 16U522



| Ref | Part | Description | Qty | Ref | Part | Description | Qty |
|-----|--------|---------------------------------------|-----|-----|--------|-------------------------------|-----|
| 531 | 514014 | RAIL, DIN; 35 mm x 7.5 mm x 8.625 in. | 1 | 534 | 24R723 | BLOCK, terminal, quad M4, ABB | 2 |
| 532 | 120838 | TERMINAL, end stop | 3 | 535 | 126453 | POWER SUPPLY, 24V | 1 |
| 533 | 24R722 | BLOCK, terminal PE, quad, ABB | 1 | 536 | 24R724 | BLOCK, terminal, UT35 | 6 |

Parts


| Ref | Part | Description | Quantity | |
|-------|--------|---|----------|--------|
| | | | 24U320 | 24U321 |
| 601 | 160327 | FITTING, union adapter, 90° | 2 | 2 |
| 602 | 118459 | FITTING, union, swivel, 3/4 in. | 2 | 2 |
| 603◆ | 247503 | MANIFOLD, strainer, inlet | 2 | 2 |
| 604 | 24U852 | THERMOMETER, dial | 2 | 2 |
| 605 | 24U853 | GAUGE, press, fluid | 2 | 2 |
| 606 | - - - | FILTER, replacement | 2 | 2 |
| 607 ◆ | C20203 | PACKING, o-ring, 1.17, fluoroelastomer | 2 | 2 |
| 608◆ | 16V879 | CAP, filter | 2 | 2 |
| 609◆ | 555808 | PLUG, 1/4mp w/ hex hd | 2 | 2 |
| 610 | 15D757 | HOUSING, thermometer, viscon hp | 2 | 2 |
| 613 | 109077 | VALVE, ball 3/4 npt | 1 | 2 |
| 614 | C20487 | FITTING, nipple, hex | 2 | |
| 614 | 624545 | FITTING, tee 3/4m run x 1/4f branc | | 2 |
| 615 | 24U851 | TRANSDUCER, pressure, temperature (includes foam) | | 2 |

* *Optional 80 mesh filter 255082 (2 pack)*


★ *Included in 24V020 Inlet Filter and Seal Kit, 20 mesh (2 pack).*

◆ *Included in 247503 Manifold Repair Kit.*


Electrical Schematics



ti22679b



INCOMING POWER DIAGRAM



16X050A

Reactor 2 Repair Spare Parts Reference

Recommended Common Spare Parts


| Ref | Part | Description | Part of Assembly |
|----------|--------|---|------------------|
| 106, 115 | 15C852 | E-30 Pump Repair Kit | Pump |
| 106, 115 | 15C851 | E-XP2 Pump Repair Kit | Pump |
| 106, 115 | 246963 | E-XP2 Wet Cup Repair Kit | Pump |
| 106, 115 | 246964 | E-30 Wet Cup Repair Kit | Pump |
| 606, 607 | 24V020 | Y-Strainer Filter and Gasket Kit (pack of two each) | Y-Strainer |
| 402 | 247824 | Drain Valve Cartridge | Fluid Manifold |
| 403 | 102814 | Fluid Pressure Gauge | Fluid Manifold |
| 405 | 15M669 | Pressure Sensor | Fluid Manifold |
| 211, 212 | 24L973 | RTD Repair Kit | Heater |
| -- | 24K207 | Hose FTS | Hose |
| -- | 24N450 | RTD Cable (50 ft. replacement) | Hose |
| -- | 24N365 | RTD Cable Test Kit (To assist measuring RTDs and RTD cable resistances) | Hose |

Performance Charts

Use these charts to help identify the proportioner that will work most efficiently with each mix chamber. Flow rates are based on a material viscosity of 60 cps.

NOTICE
 To prevent system damage, do not pressurize the system above the line for the gun tip size being used.

Proportioners For Foam



Proportioners For Coatings

Table 1 Fusion Air Purge, Round Pattern




Table 2 Fusion Air Purge, Flat Pattern




Table 3 Fusion Mechanical Purge, Round Pattern





Table 4 Fusion Mechanical Purge, Flat Pattern



Technical Specifications

| Reactor 2 E-30 and E-XP2 Proportioning System | | |
|---|--------------|-------------------|
| | U.S. | Metric |
| Maximum Fluid Working Pressure | | |
| E-30 | 2000 psi | 14 MPa, 140 bar |
| E-XP2 | 3500 psi | 24.1 MPa, 241 bar |
| Maximum Fluid Temperature | | |
| E-30 | 190°F | 88°C |
| E-XP2 | 190°F | 88°C |
| Maximum Flow Rate | | |
| E-30 | 30 lb/min | 13.5 kg/min |
| E-XP2 | 2 gpm | 7.6 lpm |
| Maximum Heated Hose Length | | |
| Length | 310 ft | 94 m |
| Output per Cycle, ISO and RES | | |
| E-30 | 0.0272 gal. | 0.1034 liter |
| E-XP2 | 0.0203 gal. | 0.0771 liter |
| Operating Ambient Temperature Range | | |
| Temperature | 20° to 120°F | -7° to 49°C |
| Line Voltage Requirement | | |
| Nominal 200–240 VAC, 1 Phase, 50/60 Hz | 195–265 VAC | |
| Nominal 200–240 VAC, 3 phase, DELTA, 50/60 Hz | 195–265 VAC | |
| Nominal 350–415 VAC, 3 phase, WYE, 50/60 Hz | 340–455 VAC | |
| Heater Power, (at 230 VAC rated voltage) | | |
| E-30 10 kW | 10,200 Watts | |
| E-30, 15 kW | 15,300 Watts | |
| E-XP2 15 kW | 15,300 Watts | |

| Sound Pressure, Sound Pressure measured per ISO-9614-2. | | |
|---|---|--------------------|
| E-30, Measured from 3.1 ft (1 m), at 1000 psi (7 MPa, 70 bar), 3 gpm (11.4 lpm) | 87.3 dBA | |
| E-XP2, Measured from 3.1 ft (1 m), at 3000 psi (21 MPa, 207 bar), 1 gpm (3.8 lpm) | 79.6 dBA | |
| Sound Power | | |
| E-30, Measured from 3.1 ft (1 m), at 1000 psi (7 MPa, 70 bar), 3 gpm (11.4 lpm) | 93.7 dBA | |
| E-XP2, Measured from 3.1 ft (1 m), at 3000 psi (21 MPa, 207 bar), 1 gpm (3.8 lpm) | 86.6 dBA | |
| Fluid Inlets | | |
| Component A (ISO) and Component B (RES) | 3/4 NPT(f) with 3/4 NPSM(f) union | |
| Fluid Outlets | | |
| Component A (ISO) | #8 (1/2 in.) JIC, with #5 (5/16 in.) JIC adapter | |
| Component B (RES) | #10 (5/8 in.) JIC, with #6 (3/8 in.) JIC adapter | |
| Fluid Circulation Ports | | |
| Size | 1/4 NPSM(m) | |
| Maximum Pressure | 250 psi | 1.75 MPa, 17.5 bar |
| Dimensions | | |
| Width | 26.3 in. | 668 mm |
| Height | 63 in. | 1600 mm |
| Depth | 15 in. | 381 mm |
| Weight | | |
| E-30, 10 kW | 315 lb | 143 kg |
| E-30, 15 kW | 350 lb | 159 kg |
| E-30, 10 kW Elite | 320 lb | 145 kg |
| E-30, 15 kW Elite | 355 lb | 161 kg |
| E-XP2 | 345 lb | 156 kg |
| E-XP Elite | 350 lb | 159 kg |
| Wetted Parts | | |
| Material | Aluminum, stainless steel, zinc plated carbon steel, brass, carbide, chrome, chemically resistant o-rings, PTFE, ultra-high molecular weight polyethylene | |

Graco Extended Warranty for Reactor® 2 Components

Graco warrants all equipment referenced in this document which is manufactured by Graco and bearing its name to be free from defects in material and workmanship on the date of sale to the original purchaser for use. With the exception of any special, extended, or limited warranty published by Graco, Graco will, for a period of twelve months from the date of sale, repair or replace any part of the equipment determined by Graco to be defective. This warranty applies only when the equipment is installed, operated and maintained in accordance with Graco's written recommendations.

| Graco Part Number | Description | Warranty Period |
|---------------------------|-------------------------|-------------------------------|
| 24U050 24U051 | Electric Motor | 36 Months or 3 Million Cycles |
| 24U831 | Motor Control Module | 36 Months or 3 Million Cycles |
| 24U832 | Motor Control Module | 36 Months or 3 Million Cycles |
| 24U855 | Heater Control Module | 36 Months or 3 Million Cycles |
| 24U854 | Advanced Display Module | 36 Months or 3 Million Cycles |
| All other Reactor 2 parts | | 12 Months |

This warranty does not cover, and Graco shall not be liable for general wear and tear, or any malfunction, damage or wear caused by faulty installation, misapplication, abrasion, corrosion, inadequate or improper maintenance, negligence, accident, tampering, or substitution of non-Graco component parts. Nor shall Graco be liable for malfunction, damage or wear caused by the incompatibility of Graco equipment with structures, accessories, equipment or materials not supplied by Graco, or the improper design, manufacture, installation, operation or maintenance of structures, accessories, equipment or materials not supplied by Graco.

This warranty is conditioned upon the prepaid return of the equipment claimed to be defective to an authorized Graco distributor for verification of the claimed defect. If the claimed defect is verified, Graco will repair or replace free of charge any defective parts. The equipment will be returned to the original purchaser transportation prepaid. If inspection of the equipment does not disclose any defect in material or workmanship, repairs will be made at a reasonable charge, which charges may include the costs of parts, labor, and transportation.

THIS WARRANTY IS EXCLUSIVE, AND IS IN LIEU OF ANY OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTY OF MERCHANTABILITY OR WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE.

Graco's sole obligation and buyer's sole remedy for any breach of warranty shall be as set forth above. The buyer agrees that no other remedy (including, but not limited to, incidental or consequential damages for lost profits, lost sales, injury to person or property, or any other incidental or consequential loss) shall be available. Any action for breach of warranty hereunder must be brought within the latter of two (2) years of the date of sale, or one (1) year the warranty period expires.

GRACO MAKES NO WARRANTY, AND DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, IN CONNECTION WITH ACCESSORIES, EQUIPMENT, MATERIALS OR COMPONENTS SOLD BUT NOT MANUFACTURED BY GRACO. These items sold, but not manufactured by Graco (such as electric motors, switches, hose, etc.), are subject to the warranty, if any, of their manufacturer. Graco will provide purchaser with reasonable assistance in making any claim for breach of these warranties.

In no event will Graco be liable for indirect, incidental, special or consequential damages resulting from Graco supplying equipment hereunder, or the furnishing, performance, or use of any products or other goods sold hereto, whether due to a breach of contract, breach of warranty, the negligence of Graco, or otherwise.

FOR GRACO CANADA CUSTOMERS

The Parties acknowledge that they have required that the present document, as well as all documents, notices and legal proceedings entered into, given or instituted pursuant hereto or relating directly or indirectly hereto, be drawn up in English. Les parties reconnaissent avoir convenu que la rédaction du présente document sera en Anglais, ainsi que tous documents, avis et procédures judiciaires exécutés, donnés ou intentés, à la suite de ou en rapport, directement ou indirectement, avec les procédures concernées.

Graco Information

For the latest information about Graco products, visit www.graco.com.

To place an order, contact your Graco Distributor or call to identify the nearest distributor.

Phone: 612-623-6921 **or Toll Free:** 1-800-328-0211 **Fax:** 612-378-3505

All written and visual data contained in this document reflects the latest product information available at the time of publication.

Graco reserves the right to make changes at any time without notice.

For patent information, see www.graco.com/patents.

Original Instructions. This manual contains English. MM 333024

Graco Headquarters: Minneapolis

International Offices: Belgium, China, Japan, Korea

GRACO INC. AND SUBSIDIARIES • P.O. BOX 1441 • MINNEAPOLIS MN 55440-1441 • USA

Copyright 2014, Graco Inc. All Graco manufacturing locations are registered to ISO 9001.

www.graco.com

Revision G, January 2016