


Burwell Air Blast Machines

Burwell 1230, 1236, 1244 and 1532 Blast Machine Parts



No	Product Code	Item Description
3	0405-3371	1" AAV Diaphragm Outlet Valve
4	0304-3004	Pop Up Valve
5	0304-3005	Pop Up Valve Guide (1230 Only)
5	0304-3606	Pop Up Valve Guide (1236 Only)
5	0304-4405	Pop Up Valve Guide (1244 Only)
6	0304-3006	Pop Up Valve Seating Rubber
7	0304-3007	Seating Ring
8	0304-3008	Hand Hole Cover, Complete
9	0304-2143	Hand Hole Cover Gasket
10	0304-3010	5" Solid Rubber Wheels
11	0304-3011	Axle Assembly (Axle, Split Pins and Washers)
12	0304-3012	Choke Valve Hose including Clamps (1230)
12	0304-4412	Choke Valve Hose including Clamps (1244)
13	0304-1473	Pressure Gauge (Rear Entry)
14	0302-2280	1" AAV Inlet Valve
15	0302-3035	Choke Valve Assembly, Complete
16	0302-6821	Micromiser Valve
*	0305-2808	Nipple, B/S 1" x 1/2" BSP Reducing
*	0502-00558	Coupling, Pot Aluminium 1/2" CFA-1/2
*	0305-1809	Nipple, B/S 1/2" BSP
*	0305-1815	Tee, 3000LB 1/2" BSP
*	0601-30206	Hose Tail, 1/2" x 1/2" BSP Male
*	0503-1319	Pin, Locking Safety
	0304-0127	Screen for 12" dia Blast Machine
	0304-0125	Lid for 12" dia Blast Machine