

## 122 Testex Replica Tape

### elcometes

## Elcometer 122 Testex® Replica Tape User Guide

#### **ABOUT TESTEX TAPE**

Elcometer 122 Testex® Tape consists of a foam with a non-compressible backing. It is used to provide a permanent mould of the peak-to-valley profile of a surface. These instructions describe the use of the following grades of Elcometer 122 Testex Tape:

Part Number (Single Roll)	Description	Profile Range
E122A1	Elcometer 122 Coarse Minus	12 to 25µm (0.5 to 1mil)
E122B1	Elcometer 122 Coarse	20 to 64µm (0.8 to 2.5mils)
E122C1	Elcometer 122 X-Coarse	38 to 115µm (1.5 to 4.5mils)
E122F1	Elcometer 122 Coarse Plus	116 to 127µm (4.6 to 5.0mils)

Bulk quantities are available to purchase. For more information or to re-order, please contact Elcometer.

#### **STANDARDS**

Elcometer 122 Testex Tape can be used in accordance with the following International Standards: ASTM D 4417-C, BS 7079-C5 (superseded), ISO 8503-5, NACE RP0287, US Navy NSI 009-32, US Navy PPI 63101-000

#### **TAKING A READING**

- 1. Tear off one section of tape from the roll, peel off the backing tape and retain the backing for future use.
- 2. Stick the tape on to the test surface, and rub the central portion using the swizzle stick provided, or the end of a pen, pencil or similar rounded object until dark spots appear. This gives a surface profile replica.
- 3. Using a micrometer such as the Elcometer 124 Foil Thickness Gauge, measure the thickness of the central portion of the tape replica and subtract 50μm (2mils) from the reading. This result is the peak-to-valley profile height. Write the value on the tape.
- 4. Replace the backing tape to preserve the imprinted profile for future reference.

www.elcometer.com

Copyright 2016 Burwell Technologies



## elcometer

The Elcometer 122 Coarse and X-Coarse tape grades have been redesigned to improve the performance in temperatures above 60°C (140°F).

This redesign has affected the overlap between the ranges of the two grades, resulting in a change in the measurement procedure.

If a measurement made with either tape grade is between 38 and 64µm (1.5 and 2.5mils), a second measurement should be taken at the same spot, with the **OTHER** grade.

If **BOTH** values are between 38 and 64µm (1.5 and 2.5mils) then the peak-to-valley height is the average of the two values. If the second value is outside this range, this should be used and the initial value discarded.




Figure 1. Tape Range Illustration

The shaded segments mark the primary range for Coarse and X-Coarse grades.

The effect of these changes is to make the Coarse and X-Coarse grade tape measurements more comparable with other means of determining profile over testex tape's primary range of 20 to 115µm (0.8 and 4.5mils)

elcometer is a registered trademark of Elcometer Limited, Edge Lane, Manchester, M43 6BU. United Kingdom © Elcometer Limited 2010-2014. All rights reserved. No part of this document may be reproduced, transmitted, transcribed, stored (in a retrieval system or otherwise) or translated into any language, in any form or by any means (electronic, mechanical, magnetic, optical, manual or otherwise) without the prior written permission of Elcometer Limited.

TMA-0486 Issue 03. Text with Cover No: 22500

www.elcometer.com



# elcometer www.elcometer.com

#### **ENGLAND**

Elcometer Limited Edge Lane Manchester M43 6BU Tel: +44 (0)161 371 6000 Fax: +44 (0)161 371 6010 e-mail: sales@elcometer.com www.elcometer.com

#### USA

Elcometer Inc 1893 Rochester Industrial Drive 896 Dunearn Rd Rochester Hills Michigan 48309 Sime Darby Centre #03-09 Tel: +1 248 650 0500 Toll Free: 800 521 0635 Fax: +1 248 650 0501 e-mail: inc@elcometer.com www.elcometer.com

#### ASIA & THE FAR EAST

Elcometer (Asia) Pte Ltd Singapore 589472, Tel: +65 6462 2822 Fax: +65 6462 2860 e-mail: asia@elcometer.com www.elcometer.com

#### **JAPAN**

Elcometer KK 7F Toranomon MT40 Bldg. 5-13-1 Toranomon, Minato-ku Tokyo 105-0001 Tel: +81 (0)3-4530-9714 Fax: +81 (0)3-4530-9713 email: jp info@elcometer.com www.elcometer.co.jp

#### BELGIUM

Elcometer SA Rue Vallée 13 B-4681 Hermalle /s Argenteau 45430 BOU Tel: +32 (0)4 379 96 10 Fax: +32 (0)4 374 06 03 e-mail: be\_info@elcometer.com e-mail: fr\_info@elcometer.com www.elcometer.be

#### **FRANCE**

Elcometer Sarl 97 Route de Chécy Tel: +33 (0)2 38 86 33 44 Fax: +33 (0)2 38 91 37 66 www.elcometer.fr

#### **GERMANY**

Elcometer Instruments GmbH Ulmer Strasse 68 D-73431 Aalen Tel: +49(0)7361528060 Fax: +49(0)7361 52806 77 e-mail: de\_info@elcometer.de www.elcometer.de

#### **THE NETHERLANDS**

Elcometer NL Newtonlaan 115 3584 BH Utrecht Tel: +31 (0)30 210.7005 Fax: +31 (0)30 210.6666 email: nl\_info@elcometer.com www.elcometer.com